

OPERATOR'S MANUAL

D65A MS/MT

Non-classifiable control system

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Plus d'informations sur : www.dbmoteurs.fr

Foreword

Thank you for purchasing this Volvo Penta diesel engine.

This manual contains operation instructions and maintenance and inspection information. In order to ensure safety and bring out the maximum performance of the engine, do not operate the engine until you have read and fully understood the contents of this manual. Do not hesitate to consult your Volvo Penta dealer.

Failure to follow the instructions and cautions in this manual may result in serious accidents.

* Keep this manual at hand for easy reference.

* If this manual is damaged or misplaced, immediately order a new copy from your dealer.

All information and illustrations in this manual are based on the specifications that were available at the time of printing. This manual does not cover all available variants of accessories and options.

Contents

Foreword	3	Fuel system	49
Contents	4	Bleeding the fuel system	49
Safety Information	5	Changing the fuel filter	51
Safety regulations during engine operation	6	Changing fuel injector nozzle	52
Safety directions for maintenance and service	8	Fuel injection pressure	53
Warning labels	11	Injection timing inspection	55
Introduction	13	Fuel control	56
Presentation	15	Twin fuel pre-filter/water separator	57
D65A MS	15	Fuel shut off valve	59
D65A MT	16	Air inlet and exhaust systems	60
New engine initial service	17	Turbocharger inspection	60
Starting	18	Cleaning the air cooler	60
Non-classifiable control system	19	Checking air cooler drain pipe	60
Instrument panels	19	Washing the air inlet silencer filter	61
Starting procedure	21	Cooling system, general	62
Operation	22	Cooling system D49A/D65A MS HE	63
Stopping the engine	23	Cooling system D49A/D65A MS KC (1 circuit) ..	64
Operation	24	Cooling system D49A/D65A MT HE	65
Stopping	29	Cooling system D49A/D65A MT KC (2 circuit) ..	66
Manual stop lever	29	Freshwater system	67
After stopping	29	Checking the coolant level	67
Anti-freezing measures	30	Filling the coolant	67
Breaks in operation [not using the genset]	30	Draining the coolant	68
Maintenance	31	Flushing the freshwater system	68
Maintenance schedule	32	Rawwater system	69
D65A MS	32	Draining the rawwater system	69
D65A MT	35	Checking/Changing zinc anodes	69
Overhaul information	38	Checking/Changing rawwater filter	69
Recommendation of Daily Operation Records	40	Checking/Changing rawwater pump impeller	70
Engine	41	Cleaning the heat exchanger	70
Valve clearance	41	Electrical system	71
Firing order	42	Protective devices inspection	71
Vibration damper inspection	43	Checking the electrical wiring	71
Re-tighten bolts and nuts	43	Starter motor inspection	71
Using the turning gear	44	Alternator inspection	71
Lubrication system	45	Checking/Adjusting/Changing the drive belts	71
Checking oil level	45	Inhibiting	72
Filling oil	45	Troubleshooting	74
Changing oil	46	Technical Data	75
Changing oil filter	47	D65A MS	75
Changing hydraulic governor oil filter	48	D65A MT	76
		Fuel specification	77
		Lubrication oil specification	78
		Coolant specification	79
		Tightening torque tables	80
		Identification numbers	86
		Sea trial data	87
		Notes	88


Safety Information

Read this chapter thoroughly. It concerns your safety. This section describes how safety information is presented in this manual and on the product. It also includes a summary of basic safety regulations for operation and maintenance of the engine.


Make sure you are in possession of the right operator's manual before reading on. If this is not the case, please get in touch with your Volvo Penta dealer.


If operations are performed incorrectly it could result in personal injury or damage to property or the engine. Read the Operator's Manual carefully before operating or servicing the engine. If anything is unclear please contact your Volvo Penta dealer for assistance.




 This symbol is used in the book and on the engine to make you aware of safety information. Always read these safety precautions very carefully.

In the Operator's Manual warning texts have the following priority:

 **WARNING!** If these instructions are not followed there is a danger of personal injury, extensive damage to the product or serious mechanical malfunction.

 **IMPORTANT!** Used to draw your attention to something that can cause damage, product malfunction or damage to property.

NOTE! Used to draw your attention to important information that will facilitate work or operations.

 This symbol is used in certain cases on our products and refers to important information in the Operator's Manual. Ensure that warning and information symbols on the engine and transmission are always visible and legible. Replace symbols that have been damaged or painted over.

Safety regulations during engine operation

The new engine

Read instruction manuals and other information accompanying the new vessel thoroughly. Accustom yourself with handling the engine, controls and other equipment in a safe and correct manner.

Remember that when operating a vessel, you have a legal responsibility to be aware of and follow regulations concerning traffic and safety at sea. Inform yourself of the regulations applicable to your vessel and the waters you are in by getting in touch with the relevant authorities or marine safety organization.

Accidents and other incidents

Sea rescue statistics show that deficient maintenance of vessels and engines together with defective safety equipment often causes accidents and other incidents at sea.

Make sure your vessel and engine are maintained in accordance with directions in the instruction manuals and that the safety equipment on board is in good working order.

Daily inspection

Make a habit of visually inspecting the engine and engine room before starting and after stopping the engine. This will help you to quickly detect any fuel, coolant or oil leaks and any other abnormalities that have occurred or are about to occur.

Maneuvering

Avoid violent and rapid rudder movement and gear shifting. There is a risk of the passengers falling down or falling overboard. A rotating propeller can cause serious injury. Make sure there is nobody in the water before engaging forward/reverse. Never run close to bathers or in places where you have reason to believe there are people in the water.

Filling fuel

There is a risk of fire and explosion when filling fuel. Smoking is prohibited and the engine must be turned off. Never overfill the tank. Close the filler cap securely. Use only fuel recommended in the operators manual. The incorrect grade of fuel can disturb operation or cause breakdown. This can also lead to the control rod jamming on diesel engines, which will cause the engine to overspeed and risk damaging machinery and causing personal injury.

Combustible environment

Due to the risk of fire and/or explosion, do not start or continue to run the engine if there is a suspected leak or discharge of combustible media, e.g. fuel oil or LPG, in the engine surroundings.

Carbon monoxide poisoning

When a vessel is moving forward, it will cause a certain vacuum to form behind the vessel. In unfortunate circumstances, the suction from this vacuum can be so great that the exhaust gases from the vessel are drawn into the bridge or cabin and cause carbon monoxide poisoning. This problem is most prevalent on high, wide vessels with abrupt stern. Other factors that can increase the effect of the suction are wind conditions, load distribution, swells, trim, open hatches and portholes, etc. Most modern vessels, however, are designed in such a way that this problem is very rare. If suction should arise anyway, do not open hatches or portholes at the fore of the vessel. Surprisingly, this will otherwise increase the suction. Try changing speed, trim, or load distribution instead. Get in touch with your Volvo Penta dealer for help in obtaining the best solution for your vessel.

⚠ IMPORTANT! Safety equipment: life jackets for everyone on board, communication equipment, distress rockets, approved fire extinguisher, bandages, life buoy, anchor, paddle, torch, etc.

- Spare parts and tools: Impeller, fuel filter, fuses, adhesive tape, hose clips, engine oil, propeller and tools for tasks it may be necessary to perform.
- Plan your desired route from the charts. Calculate distance and fuel consumption. Listen to weather reports.
- Inform relations of your planned route for long trips. Remember to inform of changed plans or delays.
- Inform the people on board of where the safety equipment is located and how it works. Make sure there is more than one person on board that knows how to start and maneuver the boat safely.

This list should be supplemented with necessary safety equipment depending on the type of boat, where and how it is being used, etc. We recommend you get in touch with a regional boat or marine safety organization to obtain more detailed marine safety information.

Safety directions for maintenance and service

⚠ Preparations

Knowledge

The operator's manual contains directions for performing normal maintenance and service in a safe and correct manner. Read the directions carefully before starting work. More detailed service literature is available from your Volvo Penta dealer. Never perform a task unless you are absolutely sure how it is to be carried out; call your Volvo Penta dealer for assistance instead.

Stop the engine

Stop the engine before opening or dismantling the engine hatch/hood. Maintenance and service must be carried out with the engine stationary unless stated otherwise in the instructions. Prevent inadvertent start of the engine by removing the starter key and turning off the power with the main switch, locking it in the off position. Place warning signs stating that service is in progress in every position from which the engine can be started. Working on or approaching a running engine is a safety hazard. Loose clothing, hair, fingers or a dropped tool can be caught in rotating parts and cause serious bodily injury. Volvo Penta recommend leaving all work requiring the engine to be running to an authorized Volvo Penta dealer.

Lifting the engine

Always use the lifting eyes mounted on the engine when lifting the engine. Always make sure lifting equipment is in good condition and constructed for the lift (engine weight together with possible reverse gear and extra equipment). Use an adjustable lifting boom to ensure safe handling when lifting the engine. All chains and wires must run parallel with each other and as much at right angle as possible to the top of the engine. Note that any extra equipment mounted on the engine can change the center of gravity. Special lifting devices may be required to obtain the right balance and safe handling. Never perform service on an engine suspended only from a lifting device.

⚠ IMPORTANT! Engine must only be lifted horizontally.

⚠ IMPORTANT! Engine lifting eyes are designed only for lifting an engine. Do not use the engine lifting eyes when lifting an engine with a gearbox mounted.

Before starting

Refit all guards and covers that have been removed before starting the engine. Make sure there are no tools or other objects left on the engine. A turbocharged engine must never be started without the air filter fitted. The rotating compressor wheel in the turbocharger can cause severe personal injury.

There is also a risk of foreign objects being drawn in and causing mechanical damage.

⚠ Fire and explosion

Fuel and lubricants

All fuels, most lubricants, and many chemicals are flammable substances. Always read and follow the directions on the packaging. Work performed on the fuel system must be done on a cold engine. Fuel leaks and spills on hot surfaces or electrical components can cause fires.

Keep oil- and fuel drenched rags and other hazardous materials where they are safe in case of fire. Oil drenched rags can selfignite in certain conditions. Never smoke when refueling, topping up with oil or when in the vicinity of the fuel station or the engine room.

Non-original parts

Components in fuel, lubrication, ignition and electrical systems on Volvo Penta engines are designed and manufactured to minimize the risk of explosion and fire in compliance with existing legislation.

The use of non-original parts can result in explosion or fire.

Batteries

Batteries contain and generate oxyhydrogen gas, especially when charging. Oxyhydrogen is easily ignited and extremely explosive. Smoking, open flames and sparks must never occur in, or close to, the batteries or battery compartment. A faulty battery connection or jumper cable can generate sparks that can cause the battery to explode.

Start spray

Never use start spray or similar start help. Explosions can occur in the intake manifold. Risk for personal injury.

⚠ Hot surfaces and fluids

At operating temperature, the engine and its components are hot. A hot engine always involves risk for burn injuries. Take care with hot surfaces. E.g.: exhaust manifold, turbocharger, oil pan, charge air pipe, starting heater, hot coolant and warm lubricant in pipes and hoses.

⚠ WARNING! Do not open the crankcase covers while the engine is still hot.

⚠ Carbon monoxide poisoning

Start the engine in well-ventilated spaces only. When running in confined spaces, the exhaust gases and crankcase gases must be evacuated.

⚠ Chemicals

Most chemicals such as glycol, anti-corrosion agent, preservatives, degreasing agent, etc., are hazardous to health. Always read and follow the directions on the packaging.

Certain chemicals such as preservatives are flammable and harmful to inhale. Provide good ventilation and use breathing protection when spraying. Always read and follow the directions on the packaging. Store chemicals and other hazardous materials out of reach of children. Leave left over or used chemicals to a destruction plant.

⚠ Cooling system

There is a risk of water entering when working on the seawater system. Therefore, stop the engine and close the seawater cock before starting work.

Avoid opening the coolant filler cap when the engine is warm. Steam or hot coolant may spurt out and cause burn injuries.

If the filler cap, coolant pipe, cock, etc., must nevertheless be opened or dismantled while the engine is warm, the filler cap must be opened carefully to release the pressure before removing it completely and starting work. Note that the coolant can still be hot and cause burn injuries.

⚠ Lubricating system

Hot oil can cause burn injuries. Avoid skin contact with warm oil. Make sure the lubricating system is depressurized before starting work. Never start or run the engine with the oil filler cap removed or there will be a risk of the oil being thrown out.

⚠ Fuel system

Always protect your hands when carrying out leak detection.

Escaping fluids under pressure can pierce bodily tissue and cause serious injury. Risk of blood poisoning. Always cover any electric component if it is located under the fuel filter. Otherwise it might be damaged by fuel spills.

⚠ Electrical system

Turn off the power before commencing work on the electrical system, the engine must be stopped and the powered turned off with the main switch/switches. Shore power to the engine heater, battery charger or other extra equipment fitted to the engine must be disconnected.

Batteries

Batteries contain a highly corrosive electrolyte. Protect your eyes, skin and clothing when charging and handling batteries. Always use protective goggles and gloves.

In case of splashes on the skin, wash with soap and plenty of water. In case of splashes in the eyes, rinse immediately with plenty of water and call a doctor.

Avoid burns and crushing or cutting!

At operating temperature, the engine coolant is hot and under pressure. Steam can cause personal injury. Check the coolant level only after the engine has been stopped and the coolant filler cap has cooled enough to touch with your hand. Never adjust the V-belts while the engine is running.

Service batteries carefully!

If you spill electrolyte on yourself, flush skin immediately with lots of water. Apply baking soda to help neutralize the acid. If electrolyte gets in your eyes, rinse immediately with large amounts of water then contact a doctor at once.

Handle antifreeze carefully!

Antifreeze contains alkali. Avoid contact with skin and eyes to prevent personal injury. Dispose of drained antifreeze coolant according to local regulations. For disposal, consult your dealer.

Dress properly for the job!

Wear protective devices - hard hat, face shield, safety shoes, goggles, heavy gloves, ear protectors, etc. - for your own safety.

Recommended fuel, lubrication oil and coolant!

Use of any other fuel oil, lubrication oil or coolant than the recommended can cause engine damage and reduce engine service life.

Perform all recommended inspections!





Perform pre-start inspection and periodic inspection on items listed in this manual. Failure to follow this recommendation can cause serious engine damage.

Warning labels

D65A MS

The engine carries 'Warning Labels' at places where you are required to pay special attention. Please read them carefully and make sure you understand the content of each label and the meaning of their position.




1. Make sure the labels are legible. If you find any letter or picture illegible in a label, remove soil from the label, or replace it.
2. Clean the label with cloth and water or cleanser. Do not use organic solvent or gasoline, this would dissolve the label's adhesive and cause the label to fall off.
3. If any label is damaged, lost or illegible, replace it. When replacing a label, make sure the new label is identical to the old one. For new labels, please contact your dealer.



D65A MT

The engine carries 'Warning Labels' at places where you are required to pay special attention. Please read them carefully and make sure you understand the content of each label and the meaning of their position.

1. Make sure the labels are legible. If you find any letter or picture illegible in a label, remove soil from the label, or replace it.
2. Clean the label with cloth and water or cleanser. Do not use organic solvent or gasoline, this would dissolve the label's adhesive and cause the label to fall off.
3. If any label is damaged, lost or illegible, replace it. When replacing a label, make sure the new label is identical to the old one. For new labels, please contact your dealer.



Introduction

This operator's manual has been produced to give you the greatest benefit of your Volvo Penta marine engine. It contains the information necessary to handle and maintain your engine in a safe and correct manner. We would like you to read this operator's manual thoroughly and learn how to handle the engine, controls and other equipment in a safe manner before starting to operate the engine.

Keep the operator's manual within reach at all times.

Care of the environment

We would all like to live in a clean and healthy environment. An environment where we can breathe clean air, see healthy trees, have clean water in our lakes and oceans, and are able to enjoy the sunshine without being worried about our health. Unfortunately, this cannot be taken for granted nowadays but is something we must work together to achieve.

As a manufacturer of marine engines, Volvo Penta has a special responsibility, why care of the environment is a core value in our product development. Today, Volvo Penta has a broad range of engines where progress has been made in reducing exhaust emissions, fuel consumption, engine noise, etc. We hope you will take care in preserving these qualities.

Always follow any advice given in the operator's manual concerning fuel grades, operation and maintenance and you will avoid causing unnecessary interference to the environment. Get in touch with your Volvo Penta dealer if you notice any changes such as increased fuel consumption exhaust smoke.

Adapt speed and distance to avoid wash and noise disturbing or injuring animal life, moored boats, jetties, etc. Leave islands and harbours in the same condition as you want to find them. Remember to always leave hazardous waste such as waste oil, coolant, paint and wash residue, flat batteries, etc., for disposal at a destruction plant. Our joint efforts will make a valuable contribution to our environment.

Fuel and oil

Use only fuel and lubrication oil grades recommended in the technical data section of this Operator's Manual. Other grades can cause operational problems, increase fuel consumption and have long-range effects on engine service life.

Service and spare parts

Volvo Penta marine engines are designed for high operational reliability and long service life. They are constructed to withstand the marine environment while affecting it as little as possible. Through regular service and the use of Volvo Penta original spare parts, these qualities will be retained.

The worldwide Volvo Penta network of authorized dealers is at your service. They are specialists in Volvo Penta products and stock accessories, original spare parts, test equipment and the special tools required to perform high-quality service and repairs.

Always follow the maintenance intervals specified in the operator's manual and remember to specify the engine number when ordering service and spare parts.

Certified engines

It is essential that owners and operators of emission certified engines, used in areas where exhaust emissions are regulated by law, are aware of the following points:

A certification involves the engine type being checked and approved by applicable authorities. Engine manufacturers guarantee that all engines of the same type correspond with the certified engine.

This puts special demands on the maintenance and service of your engine:

- * Maintenance and service intervals recommended by Volvo Penta must be followed.
- * Only Volvo Penta original spare parts may be used.
- * Service of injector pumps, pump settings and injectors must always be performed by an authorized Volvo Penta service person.
- * The engine must not be modified in any way with the exception of accessories and service kits approved by Volvo Penta for use on the engine.
- * Installation modifications must not be made to the engine exhaust pipe or inlet channels.
- * Sealed sections must not be broken by anyone other than authorized personnel.

Otherwise, general directions concerning running, care and maintenance given in the operator's manual apply.

⚠ IMPORTANT! Neglected or deficient maintenance/service and the use of non-original spare parts will entail Volvo Penta renouncing any responsibility for the engine corresponding to the certified version. Volvo Penta will not compensate for damage and/or costs arising from the above.

Warranty

Your new Volvo Penta marine engine is covered by a limited warranty complying with the conditions and instructions given in the Warranty and Service Book.

Note that AB Volvo Penta's responsibility is limited to what is specified in the Warranty and Service Book. Read it carefully as soon as possible after delivery. It contains important information concerning the warranty card, service, maintenance and what the owner is responsible to be aware of, check and perform. AB Volvo Penta will otherwise decline warranty liability completely or fully.


Get in touch with your Volvo Penta dealer if you have not received a Warranty and Service Book or a copy of the warranty card.

Presentation


D65A MS

The D65A MS is a direct injection, 16-cylinder, 4-stroke V-engine. It is equipped with two turbochargers and fitted with either a heat exchanger for thermostat-regulated freshwater cooling or connections for keel cooling.

An optimal combination of combustion chambers, fuel injection system, effective turbocharger and charge air cooling, provide excellent fuel consumption over the whole range of speeds where the engine is economical in operation.




1. Fuel filters
2. Oil cooler
3. Fuel injection pump
4. Governor oil filter
5. Manual stop lever
6. Governor
7. Stop solenoid
8. Oil dipstick
9. Fuel feed pump
10. Oil filler cap
11. Freshwater pump
12. Lifting eye
13. Intake air silencer
14. Turbocharger
15. Alternator
16. Oil filters
17. Engine oil drain pipe
18. Starter motor
19. Manual speed control knob




D65A MT

The D65A MT is a direct injection, 16-cylinder, 4-stroke V-engine. It is equipped with two turbochargers and fitted with either a heat exchanger for thermostat-regulated freshwater cooling or connections for keel cooling.

An optimal combination of combustion chambers, fuel injection system, effective turbocharger and charge air cooling, provide excellent fuel consumption over the whole range of speeds where the engine is economical in operation.



1. Fuel filters
2. Oil cooler
3. Fuel injection pump
4. Governor oil filter
5. Manual stop lever
6. Governor
7. Stop solenoid
8. Oil dipstick
9. Fuel feed pump
10. Oil filler cap
11. Freshwater pump
12. Lifting eye
13. Intake air silencer
14. Turbocharger
15. Heat exchanger
16. Oil filters
17. Starter motor
18. Engine oil drain pipe
19. Rawwater pump
20. Alternator
21. Manual speed control knob



New engine initial service

General

Before starting a new or reconditioned engine for the first time, give it an initial inspection. This to guarantee your own safety as well as the maximum service life of the engine.

External inspection

1. Check the engine control system for loose terminals.
2. Check defects of engine parts.
3. Check the following components for loose bolts or nuts:
 - * Plugs and covers of fuel, lubrication and cooling system
 - * Coupling of fuel injection pump and shaft
 - * Crankshaft pulley and vibration damper
 - * Mounting brackets
 - * Fuel control linkage
 - * Turbocharger
 - * Timing gear case
 - * Exhaust manifolds
 - * Cylinder heads
 - * Air-duct connection-hose clamp
4. Check for fuel, oil, coolant and air leaks and repair if needed.
5. Make commissioning report for new or overhauled engine.

⚠ IMPORTANT! All covers must be mounted before attempting to start your engine.

Valves and plugs

Make sure the following valves and plugs are open or closed properly:

Fuel supply valve	Open
Coolant drain cock (engine)	Closed
Coolant drain cock (water pump)	Closed
Coolant drain cock (heat exchanger)	Closed

⚠ IMPORTANT! If the coolant drain cocks are not closed the coolant will drain from the engine and this may cause severe damage to the engine.

Electrical wiring

Check for loose or damaged electrical wiring around the engine and if necessary firmly reconnect to terminals or cable-joint portions. Damaged cables must be replaced.

If your engine is reconditioned, make sure the wiring is according to the drawings.

Filling the fuel system

Refer to chapter "Maintenance: Fuel system".

Filling the lubrication system

Refer to chapter "Maintenance: Lubrication system".

Filling the cooling system

Refer to chapter "Maintenance: Cooling system".

Starting

Before starting

- ⚠ WARNING!** Before starting the engine make sure that neither people, nor tools, are in contact with moving parts of the engine. Notify the people in the vicinity of the engine when starting it.
- ⚠ WARNING!** Make sure that you know how to stop the engine before you start it (in case of emergency). If you are starting the engine for the first time, have someone stand-by at the emergency stop lever to stop the engine in case abnormal noise occurs during start up. Block air intake in case of stop lever malfunction, this has to be prepared in advance.
- ⚠ WARNING!** Make sure that the manual speed control knob is locked in neutral position before starting the engine (refer to page 26 of this manual).
- ⚠ IMPORTANT!** If the starter motor has been engaged for the maximum time (30 seconds), it must be allowed to cool down for at least one minute before a new attempt is made at starting.

Warming-up



- ⚠ WARNING!** Do not conduct warm-up operation for an extended period of time. Prolonged warm-up operation causes carbon buildup in the cylinders that leads to imperfect combustion.
- * Operate at low idle speed for 5 to 10 minutes to warm up the engine.
- * The oil pressure will be 0.20 to 0.29 MPa [28 to 43 psi] after the warm-up run. If the engine speed is increased immediately after start-up, the oil pressure will exceed the normal level - 0.49 to 0.64 MPa [71 to 92 psi] (at rated speed) but it will normalize with increasing oil temperature.
- * If the Lubrication oil pressure does not increase when you have started the engine, immediately stop the engine and do not restart until the problem has been fixed.
- * Make sure that the cooling water flow is sufficient.
- * Make sure there is enough fuel aboard the vessel for the planned duration of operation.

Non-classifiable control system

This chapter describes the non-classifiable control system which is available for your engine. Note that that tachometer, oil gauge, temperature gauge, charge gauge, starting switch, etc., that are shown here as panel mounted, in some cases may be mounted separately.

If the vessel is equipped with instruments not described here and you are not sure of their function, please get in touch with the shipyard or the company that installed the installation aboard the vessel.

! IMPORTANT! Read the chapter “Starting” before starting your engine.




Instrument panels

Instrumentation for the main control position and auxiliary control position.

1. Temperature gauge. Indicates the engine coolant temperature.
2. Oil pressure gauge. Indicates the pressure of the engine lubricant.
3. Voltmeter. Indicates the charge voltage from the generator when the engine is running and the battery voltage when the engine is stopped.
4. Tachometer. Indicates the speed of the engine in rpm.
5. Hour counter. Shows the total number of engine running hours as a decimal number.
6. Press button for testing and acknowledging alarms (see next page “Warning displays”).
7. Siren for acoustic alarm that sounds if one of the warning lamps comes on.
8. Warning display (see section “Warning displays”, pos 1–3).
9. Starting switch (see next page).
10. Press button for instrument illumination.


11. Oil pressure gauge. Indicates the oil pressure in the reverse gear.
12. Charge air pressure gauge. Indicates the turbo-charger boost pressure.



Warning displays

If the acoustic alarm sounds, one of the warning display lamps will immediately start to flash to indicate the cause of the alarm.

1. High coolant temperature.
2. Low lubricant pressure.
3. Generator not charging




ALARM TEST

After an alarm

Press the "Alarm test" button to acknowledge and terminate the acoustic alarm. The relevant warning lamp will continue to flash until the fault has been rectified.

Alarm test




After pressing the "Alarm test" button, the warning lamps will come on and the acoustic alarm will start to sound. Make a habit of always performing an alarm test before starting.



Starting switch

Together with the starter keys a plate containing the key code is delivered. This code is required when ordering additional starter keys. Keep the code in a safe place.

- S** = Stop position.
- 0** = Key can be inserted and removed.
- I** = Voltage on (drive position).
- II** = Not used
- III** = Start position.



Starting procedure

1. Disengage the reverse gear and make sure the turning gear is not engaged. Put the control lever into neutral and idle on all control positions

⚠ WARNING! If the vessel is equipped with controls that allow starting the engine in gear, it is essential to check all control positions to make sure a gear is not engaged.

2. Turn on the power by putting the starter key in position "I".

3. Check warning lamps and alarms. Press the "Alarm test" button on the instrument panel to make sure the warning lamps come on and the acoustic alarm sounds.

4. Start the engine. Start using the starting switch. Turn the key to position "III". Release the key so that it returns to "I" immediately after the engine has started.

⚠ IMPORTANT! If the starter motor has been engaged for the maximum time (30 seconds), it must be allowed to cool down for at least one minute before a new attempt is made at starting.

NOTE! The key must first be turned to "S" before making a new attempt at starting.

5. Check the instruments and run the engine warm. Let the engine idle for the first ten seconds and make sure the instruments and warning display show normal values. Then run the engine at low speed and low load so it attains normal operating temperature before using full power.


⚠ IMPORTANT! Do not race the engine when it is cold.

Operation

Learn how to handle the engine, controls and other equipment in a safe and correct manner before taking it into operation.


Checking the instruments

Check the instruments and warning display directly after start and regularly during operation.



Oil pressure

During operation, the oil pressure gauge should show a reading of 0,50 - 0,64 MPa (71 - 93 psi). A lower value is normal at idling speed. The acoustic alarm will sound automatically in case of low oil pressure.




Coolant temperature

During operation, the temperature gauge should show a reading of 71–85°C (160–185°F). The acoustic alarm will sound automatically in case the coolant temperature is too high.



Charging

During operation, the charge voltage gauge should show a reading of 28V. The acoustic alarm will sound automatically in case the charge voltage is missing.



Alarms and fault indication

If the acoustic alarm sounds, one of the warning display lamps will immediately start to flash to indicate the cause of the alarm: High coolant temperature (1), low oil pressure (2) and no charge voltage (3).

⚠ IMPORTANT! Stop the engine immediately after an alarm for low oil pressure. Investigate the cause and rectify it.

⚠ IMPORTANT! Slow the engine speed to idle/disengaged after an alarm for high coolant temperature. If temperature does not drop, the engine must be stopped. Investigate the cause and rectify it.

Stopping the engine


Let the engine run at low idling speed (in neutral) for at least three minutes before turning it off. This will keep the engine temperature in balance and prevent it boiling.

⚠ IMPORTANT! The procedure described above is especially important if the engine has been run hard and/or exerted to heavy loads.

Stop

1. Disengage the marine gear by moving the lever to neutral position.
2. Turn the key to stop position "S".
3. Hold the key in position until the engine has stopped (the key will return to "0" automatically when released and can then be removed).

NOTE! The stop solenoid will be activated for approximately 40 seconds after stopping the engine, but the engine can be restarted at any time.



Emergency stop

If a fault occurs that prevents the engine being stopped by the normal method, it can be stopped manually using the lever mounted on the engine. Move the lever in the direction of the arrow and hold it there until the engine has stopped.


⚠ WARNING! Working on or approaching a running engine is a safety hazard. Beware of rotating parts and hot surfaces.


⚠ WARNING! Never try to increase engine rpm with the emergency stop lever since this will make the engine overspeed and this will damage the engine.


Operation


General


Learn how to handle the engine, controls and other equipment in a safe and correct manner before starting the engine


 **WARNING!** Stay clear of all rotating and moving parts during operation.


 **IMPORTANT!** Always keep the engine room well ventilated. Insufficient air supply to the engine means imperfect combustion and a loss of power.

 **IMPORTANT!** During the first 50 hours of operation, operate the engine under a lighter load and lower speeds than normal for break-in. Proper break-in contributes to maximum service life of the engine.

 **IMPORTANT!** Do not turn OFF the battery switch when the engine is running since this may damage the alternator.

 **WARNING!** At operating temperature, the engine and its components are hot. A hot engine always involves risk for burn injuries. Take care with hot surfaces. E.g.: exhaust manifold, turbocharger, oil pan, charge air pipe, starting heater, hot coolant and warm lubricant in pipes and hoses.

 **IMPORTANT!** Avoid overloading. This can cause incomplete fuel combustion often indicated by black exhaust, high fuel consumption and carbon deposits in combustion chambers, affecting engine life.

 **IMPORTANT!** Do not turn the starter switch key to the START position when the engine is running this may damage the starter.

Applying load

When the engine has reached operation temperature, bring the engine to operating speed and apply the load gradually.

During load operation make sure that:

1. No engine related alarms occur.
2. There are no visible leaks of fuel, lube oil, coolant or exhaust gas
3. No abnormal noise or vibrations occur.
4. The color of the exhaust gas is normal.
5. The breather mist is of normal quantity and color.
6. Instrument readings are the normal.*
 - *Oil pressure: 0,50 to 0,64 Mpa (71 to 92 psi) (at rated speed)
 - *Coolant temperature: 71 to 85°C (165 to 185 °F)

Running in

The engine must be “run in” during the first 10 hours of operation as follows:

Run the engine under normal operation. Do not run it at full power except for short periods. Never run the engine for long periods at constant rpm during this time. A high consumption of lubricant is normal during the running in period. Therefore, check the oil level more often than recommended. The prescribed warranty inspection “First Service Inspection” must be carried out during this first period of operation. For more information: See Warranty and Service Book.

Forced propeller rotation

When the vessel is towed or anchoring in strong currents, the propeller can make the propeller shaft rotate even though the engine is stationary. This may damage the marine gear.

Manoeuvring

The marine gear must be engaged at low idling speed. There must be a brief pause after engaging gear before increasing the engine speed. Wait for approximately two seconds to ensure that the gear clutch has engaged properly.

⚠ IMPORTANT! If the vessel is equipped with two engines equipped with wet exhaust systems, they must both be running while in reverse or there will be a risk of water entering the engine (through the exhaust passage).


Pulling away

1. Move the lever from neutral to the engagement position for the desired direction of travel.
2. Apply load accordingly.

Forward–Reverse

1. Slow the engine speed to idling and allow the vessel to lose most of its speed.
2. Move the lever to neutral.
3. Move the lever to reverse. Wait for approximately two seconds and then increase the engine speed gradually.


⚠ IMPORTANT! A direct forward–reverse maneuver can damage the marine gear and engine. It is therefore always necessary to stop with the lever in neutral for a few seconds and allow the vessel to lose most of its speed before engaging. If the speed of the vessel is too high, there is a risk of the propeller windmilling which might cause the engine to stop and start rotating in the wrong direction. This may cause serious engine damage.




Manual speed control

Manual speed adjustment of the engine can be done using the manual speed control knob.

1. Disconnect the control cable connected to the remote speed adjustment.




2. Turn the Lock counterclockwise to unlock the manual speed adjustment knob.




3. By pushing the button and pulling the knob towards you the engine speed will increase. By bushing the knob towards the engine the engine speed will decrease.

⚠ WARNING! When adjusting engine speed avoid quick changes since this may harm the engine.




4. Fine-tuning of the engine speed can be done by turning the control knob:

Turn the knob clockwise to decrease engine speed. Turn it counterclockwise to increase engine speed.



5. Bring the manual speed control knob in the neutral position when ready with the manual speed adjustment. Turn the lock clockwise to secure the installation.



6. Connect the control cable for remote speed adjustment so that the engine can be controlled from the normal position.



Start using auxiliary batteries

⚠ WARNING! Ventilate well. Batteries generate oxyhydrogen gas, which is extremely flammable and explosive. A short circuit, naked flame or spark can cause a powerful explosion.

Never reverse the polarity of the battery. Risk of sparks and explosion.

1. Make sure the rated voltage of the auxiliary battery is the same as the system voltage of the engine.
2. Connect the red auxiliary cable to the discharged battery's + terminal and then to the auxiliary battery's + terminal.
3. Connect the black jump lead to the auxiliary battery negative terminal and then to a position slightly away from the discharged batteries, for example at the negative cable's connection to the starter motor.

⚠ WARNING! The black auxiliary cable (-) must not come in contact with the positive connection on the starter motor.

4. Start the engine and run at fast idling speed for about ten minutes to charge the batteries.

⚠ WARNING! Working on or approaching a running engine is a safety hazard. Beware of rotating parts and hot surfaces.

⚠ WARNING! Do not touch the connections while attempting to start; Risk of sparks. Do not bend over the batteries either.

5. Stop the engine. Remove the auxiliary cables in reverse order to connecting.


Stopping

Allow the engine to run at low idling speed (in neutral) for at least 5 to 6 minutes before turning it off. This will keep the engine temperature in balance and prevent it from boiling.

⚠ IMPORTANT! The procedure described above is especially important if the engine has been run hard and/or exerted to heavy loads.

⚠ IMPORTANT! Do not rev up the engine just before stopping it.

⚠ IMPORTANT! If the engine stops abnormally, try to locate the problem and make the repairs needed before starting again. After starting the engine, make sure the engine runs properly.



Manual stop lever

By pulling the manual stop lever in the “STOP” direction the engine can be stopped manually. Use this lever only in an emergency when the engine can not be stopped by the engine control system.

⚠ IMPORTANT! When stopping the engine by pulling the stop lever, continue to pull the lever until the engine stops “rocking.”

Notice: If the engine cannot be stopped with the manual stop lever, shut off the fuel supply or block air intake to turbo.

After stopping

General


- * Check the genset and engine room for leaks.
- * Close the fuel cock and rawwater cock.
- * Read off the hour counter and carry out preventive maintenance according to the maintenance schedule.
- * Turn off the main switch if the genset is not to be used for a long period.


⚠ IMPORTANT! Never turn the power off using the main switch while the genset is running. This can damage the alternator.

⚠ IMPORTANT! Make sure the generator heater is working properly to avoid condensation in the generator

Anti-freezing measures


If the engine room cannot be protected from frost, the rawwater system must be drained (if it contains rawwater) and the coolant in the freshwater system must contain the right mix of anti-freeze and water. Refer to chapter Maintenance "Rawwater system" and "Freshwater system" respectively.

 **WARNING!** If the rawwater system bursts due to freezing, the vessel could sink.

 **IMPORTANT!** If the coolant does not give sufficient anti-freeze protection, it may cause costly damage to the engine. Check the charge of the battery. A poorly charged battery can freeze and break.

Breaks in operation [not using the genset]

During periods out of service, the engine must be run warm once a fortnight. This will prevent it from corroding.

 **IMPORTANT!** The genset must be conserved if it is not to be used for longer than two months. Refer to chapter Inhibiting.

Maintenance

Your Volvo Penta engine and associated equipment is designed to provide high operational reliability and long service life. They are constructed to withstand the marine environment while also affecting it as little as possible.

Preventive maintenance in accordance with the maintenance schedule will ensure that it retains these qualities and avoid unnecessary operational disturbances. The following chapters contain general technical information and directions for carrying out the prescribed maintenance points. Read the directions carefully before starting work.

The maintenance schedule shows the standard service intervals. When you think the engine should be serviced more frequently due to particular operating conditions, adjust the intervals accordingly. Appropriate service intervals vary with usage and operating conditions and with fuel, lubricant and coolant used. Due to particular operating conditions the service intervals may be adjusted accordingly. Consult your Volvo Penta dealer.

NOTE! Dust and foreign particles are the most common cause of excessive wear of parts. When disassembling a component, take measures to prevent dust and foreign particles from entering it.

Daily operation records

It is recommended to keep daily operation records. Daily recording is a preventive maintenance program and when comparing values with engine history it will help you recognize conditions, signs or indications of approaching trouble. Daily operation records also make trouble shooting easier and will lessen the down time (to save time and money for servicing).

Maintenance records


Volvo Penta recommends that accurate maintenance records are kept. With accurate maintenance records your Volvo Penta Dealer can help in fine tuning the recommended service intervals to meet the specific operating situation. This should result in a lower engine operation cost.


Fluids


It is also important to keep record of the fluids used in the engine. If brand or type of fuel, lubrication oil or coolant is changed this should be recorded.


Warranty inspection

The prescribed warranty inspection "First Service Inspection" must be carried out at an authorized Volvo Penta workshop during this first period of operation. Directions for when and where this is to be carried out can be found in the **Warranty and Service Book**.

 **WARNING!** Read the safety directions for maintenance and service in the chapter "Safety information" before starting work.

 **WARNING!** Read the chapter "Maintenance" thoroughly before starting any maintenance work. It contains directions for performing maintenance in a safe and correct manner.

 **WARNING!** Working on or approaching a running engine is a safety hazard. Maintenance and service must be carried out with the engine stationary unless stated otherwise in the instructions. Prevent inadvertent start of the engine by disabling the start-button and turning off the power with the main switch, locking it in the off position.

 **WARNING!** Place warning signs stating that service is in progress in every position from which the engine can be started.

 **IMPORTANT!** Handle parts carefully. Use only original Volvo Penta spare parts.

NOTE! When both operating time and calendar time is given, the one occurring first is to apply.

NOTE! For generator related maintenance information, refer to Generator Manufacturers information.

Maintenance schedule

D65A MS

Daily before first start

- General inspection engine and engine room
- Check and make sure all valves are in the right position
- Check lubrication oil level
- Check marine gear oil level
- Check coolant level
- Drain water from fuel tank
- Drain water from fuel pre-filter/water separator
- Drain water from air vessel and air filter
- Check engine control system (cables, etc.)
- Check fuel control linkage
- Check aftercooler drain pipe
- Daily operation records
- Inspection of valves and plugs

After start

- Check lubrication oil filter differential pressure indicator
- Check air-filter differential pressure indicator
- Check if the instrumentation works properly
- Check for leakages

Weekly

- Check starting batteries; electrolyte level/load
- Check electrical system for loose terminals/contacts
- Check foundation bolts
- Check lubrication oil for abnormal smell or water dilution
- Check safety valves of air system
- Check air system oiler
- Check settings of valves and move valve to keep them operationable
- Drain water from the fuel pre-filter/water separator

First 50-250 operating hours of new or recond. engines (First service)

- Change lubrication oil
- Change full flow lubrication oil filters
- Change governor lubrication oil filter
- Check required lubrication oil change for marine gear
- Check/adjust V-belts
- Check/adjust valve clearance
- Check/retighten bolts and nuts
- Drain crankcase ventilation water trap
- Drain exhaust silencer (system) water trap

Every 250 operating hours or every 12 months

Change lubrication oil. Longer interval requires oil analysis
Change full flow and by-pass lubrication oil filters
Check/adjust V-belts
Check rawwater filter
Check/wash air inlet silencer filter

Every 500 operating hours or every 12 months

Change governor lubrication oil filter

Every 1000 operating hours or every 12 months

Change fuel filter elements
Change filter elements of the fuel pre-filter/water separator
Check air filter (if installed)
Check/retighten bolts and nuts
Check/adjust fuel injection timing
Check/adjust fuel injection pressure and spray pattern
Change fuel injection nozzle o-rings
Check and adjust valve clearance and valve mechanism

Every 2000 operating hours or every 12 months

Check/adjust valve clearance. Check valvemechanism
Check turbocharger
Check starter motor
Check alternator
Check fuel injection pump flex drive plates
Check fuel injection pump control rack operation
Check fuel rack control "ball joints"
Check/clean charge air cooler(s)
Check/clean cooling water heat exchanger
Check coolant concentration
Check torsional vibration dampers
Check alarm and shut-down functions
Check engine control panel functions
Change V-belts
Change fuel pre-filter/water separator element
Check/change zinc anodes
Change air inlet silencer filter

Every 4000 to 6000 operating hours or every 24 months

Full service inspection⁽¹⁾

Every 12 months

Check rubber engine mounts

Check rubber hoses and flex connections

Check engine room ventilation fans

Every 10000 operating hours

Check torsional vibration damper temp check

Check rubber of flexible coupling for deformation and cracks

Replace ball-joints in fuel pump control linkage

Every 15000 operating hours

Full service inspection⁽²⁾

Every 24 months

Change coolant

(1) Every 4000 to 6000 hours or every 24 months

Have an authorized dealer execute a full service inspection of your engine including:

Endoscopic investigation of cyl heads and liners

Replace all injector nozzles

Change water pump seals

Checking and cleaning of charge air cooler

Check turbo charger

Check battery-charging alternator

Check and test stop solenoid or fuel shut-off valve

(2) Every 15000 hours

Have an authorized dealer execute a full service inspection of your engine including:

As described at 4000 – 6000 hrs

Remove and inspect one piston, piston rings and liner

Inspect crankshaft and one bearing

Inspect camshaft and one bearing

D65A MT

Daily before first start

- General inspection engine and engine room
- Check and make sure all valves are in the right position
- Check lubrication oil level
- Check marine gear oil level
- Check coolant level
- Drain water from fuel tank
- Drain water from fuel pre-filter/water separator
- Drain water from air vessel and air filter
- Check engine control system (cables, etc.)
- Check fuel control linkage
- Check aftercooler drain pipe
- Daily operation records
- Inspection of valves and plugs

After start

- Check lubrication oil filter differential pressure indicator
- Check air-filter differential pressure indicator
- Check if the instrumentation works properly
- Check for leakages

Weekly

- Check starting batteries; electrolyte level/load
- Check electrical system for loose terminals/contacts
- Check foundation bolts
- Check lubrication oil for abnormal smell or waterdilution
- Check safety valves of air system
- Check air system oiler
- Check settings of valves and move valve to keep them operationable
- Drain water from the fuel pre-filter/water separator

First 50-250 operating hours of new or recon. engines (First service)

- Change lubrication oil
- Change full flow lubrication oil filters
- Change governor lubrication oil filter
- Check required lubrication oil change for marine gear
- Check/adjust V-belts
- Check/adjust valve clearance
- Check/retighten bolts and nuts
- Drain crankcase ventilation water trap
- Drain exhaust silencer (system) water trap

Every 250 operating hours or every 12 months

Change lubrication oil. Longer interval requires oil analysis
Change full flow and by-pass lubrication oil filters
Check/adjust V-belts
Check rawwater filter
Check/wash air inlet silencer filter

Every 500 operating hours or every 12 months

Change governor lubrication oil filter

Every 1000 operating hours or every 12 months

Change fuel filter elements
Change filter elements of the fuel pre-filter/water separator
Check air filter (if installed)
Check/retighten bolts and nuts
Check/adjust fuel injection timing
Check/adjust fuel injection pressure and spray pattern
Change fuel injection nozzle o-rings
Check and adjust valve clearance and valve mechanism

Every 2000 operating hours or every 12 months

Check/adjust valve clearance. Check valvemechanism
Check turbocharger
Check starter motor
Check alternator
Check fuel injection pump flex drive plates
Check fuel injection pump control rack operation
Check fuel rack control "ball joints"
Check/clean charge air cooler(s)
Check/clean cooling water heat exchanger
Check coolant concentration
Check torsional vibration dampers
Check alarm and shut-down functions
Check engine control panel functions
Change V-belts
Change fuel pre-filter/water separator element
Check/change zinc anodes
Change air inlet silencer filter

Every 4000 to 6000 operating hours or every 24 months

Full service inspection⁽¹⁾

Every 12 months

Check rubber engine mounts

Check rubber hoses and flex connections

Check engine room ventilation fans

Every 10000 operating hours

Check torsional vibration damper temp check

Check rubber of flexible coupling for deformation and cracks

Replace ball-joints in fuel pump control linkage

Every 15000 operating hours

Full service inspection⁽²⁾

Every 24 months

Change coolant

(1) Every 4000 to 6000 hours or every 24 months

Have an authorized dealer execute a full service inspection of your engine including:

Endoscopic investigation of cyl heads and liners

Replace all injector nozzles

Change water pump seals

Checking and cleaning of charge air cooler

Check turbo charger

Check battery-charging alternator

Check and test stop solenoid or fuel shut-off valve

(2) Every 15000 hours

Have an authorized dealer execute a full service inspection of your engine including:

As described at 4000 – 6000 hrs

Remove and inspect one piston, piston rings and liner

Inspect crankshaft and one bearing

Inspect camshaft and one bearing

Overhaul information

Top overhaul

Dependent of your application, working conditions and service level a “top overhaul” might be required in case of:

Gas leakage through valves

Too much valve clearance

Low compression pressure

Top overhaul includes:

Remove cylinder heads and check liners and combustion chambers of pistons

Disassemble cylinder heads

Check inlet and exhaust valves, check valve seats (lap if necessary)

Check piston top

Check cylinder liner

Check instruments, alarms and shutdown functions

Check pipe clamp contact

Change freshwater pump seals

Change rawwater pump seals

Overhaul turbo charger

Check vibration damper on burrs and leaks

Check exhaust pipe joints

Check governor control linkage

1st major overhaul

Dependent of your application, working conditions and service level a “major overhaul” might be required in case of:

Decreased power output

Increased fuel consumption

Increased lubrication oil consumption

Increased blow-by gases

Gas leakage through valves

Starting problems

Increased noise from engine parts

Abnormal color of exhaust gases from warm engine

Major overhaul includes:

Disassemble engine, clean, check and change major parts.

Major parts:

Inlet and exhaust valve seats

Inlet and exhaust valves

Valve rotators

Valve cotters

Rocker arm adjusting screws

Valve push rods

Bridge caps

Camshaft bushings

Camshaft expansion plugs

Lubrication oil pump

Main bearings

Cylinder liners

Main bearing cap bolts and washers

Piston rings

Connecting rod bearings

Vibration damper

Air duct rubber hoses

Cooling water rubber hoses

Consumable items (gaskets, oil seals, o-rings, etc.)

Change the torsional vibration damper

2nd major overhaul

Disassemble engine, clean, check and change major parts.

Major parts:

Inlet and exhaust valve seats

Inlet and exhaust valves

Valve rotators

Valve cotters

Rocker arm adjusting screws

Valve push rods

Bridge caps

Camshaft bushings

Camshaft expansion plugs

Cylinder head bolts

Valve guides

Valve bridge guides

Valve bridges

Valve springs

Tappets

Camshaft thrust plates

Main bearings

Cylinder liners

Main bearing cap bolts and washers

Piston rings

Connecting rod bearings

Vibration damper

Air duct rubber hoses

Cooling water rubber hoses

Consumable items (gaskets, oil seals, o-rings, etc.)

Rocker bushings

Thrust plate crankshaft

Pistons and piston pins

Connecting rod bolts

Connecting rod bushings etc.

Check high-pressure fuel injection pump and fuel supply pump

Change torsional vibration damper


Recommendation of Daily Operation Records

Daily recording is a preventive maintenance program and when comparing values with engine history it will help you recognize conditions, signs or indications of approaching trouble. Daily operation records also make trouble shooting easier and will lessen the down time (to save time and money for servicing).

Items to be recorded

The following items are recommended to be recorded once a day:

1. Operating hours.
2. The amount of lubrication oil and coolant (fresh water) required for refilling. Fuel consumption.
3. Lubrication oil and coolant (fresh water) changes.
4. Lubrication oil pressure and temperature, engine rpm, exhaust temperature, coolant temperature, and charge air temperature and pressure.
5. Rawwater pressure and rawwater temperature before and after heat exchanger. Ambient temperature and engine room temperature at turbo charger inlet.
6. Parts serviced and kinds of service (adjustment, repairs or replacement).
7. Change in operating conditions (for example, "Exhaust smoke turned black," etc.)




Engine

Valve clearance

Check and adjust the valve clearance on a cold engine. The valves are adjusted when the piston is at top dead center of compression stroke. The valve bridge is adjusted first, and then the clearance of the rocker arm.

⚠ IMPORTANT! The engine must under no circumstances be running when checking and adjusting the valve clearance since the valves can knock against the pistons and cause serious damage.

⚠ IMPORTANT! Make sure that the stop lever is pulled out and the starter key switched off.





Top dead center on compression stroke

1. Turn the engine in the normal direction to align the timing mark [1.6] on the damper with the pointer as shown.
2. Remove the rocker cover of the cylinder on which the valve clearance is to be checked and adjusted, and make sure the inlet and exhaust valves have some clearance. If the timing mark [1.6] is aligned with the pointer, either the No. 1 or No. 6 piston is at top dead center on the compression stroke.

Adjusting the valve bridge


⚠ IMPORTANT! Make sure the clearance between the valve bridge and valve rotator is 1.5 mm [0.059 in.] or more if not, interference will occur between the bridge and rotator to cause the valve cones to get out of place. If the clearance is less than 1.5 mm [0.059 in.] after the height of valves has been adjusted, consult your dealer.



NOTE! Before inspecting the valve clearance, adjust the height of the two valves. Bring the bridge into contact with the valves, by means of the valve-bridge adjusting screw, so that there is no difference in height between the two valves. If the valve seats are worn, one valve will differ from another in height, increasing the clearance between the valve stem and yoke, leading to an increased valve clearance.

1. Unscrew the lock nut and adjusting screw on the pair of valves on the cylinder so that there is clearance between the yoke and the valve stem.
2. Press the valve yoke down. Turn the adjusting screw so that it makes contact with the valve stem.
3. Turn an additional 10 degrees. Lock the adjusting screw with the lock nut.

NOTE! Check if the bridge is properly adjusted, by putting a little drop of oil the valve stem top.



Valve clearance inspection


1. Check the valve clearance with feeler gauges inserted between the rocker arm and yoke cap.

Valve Clearance:

Inlet valve 0.6 mm [0.024 in.]
 Exhaust valve 0.8 mm [0.031 in.]

2. The clearance is correct if feeler gauge is slightly gripped between the rocker arm and the yoke cap. If the feeler does not fit into the clearance exactly, perform adjustments as described below.

⚠ IMPORTANT! When performing the "First Service", valves that are checked and deemed not in need of adjustment must be checked again within 250 hours.



Adjust valve clearance

1. Loosen the lock nut of the adjusting screw.
2. Turn in or back off the adjusting screw so that feeler gauge is slightly gripped between the rocker arm and yoke cap.
3. After adjusting the clearance, tighten the lock nut of the adjusting screw.


Firing order

Check and adjust the valve clearance in the firing order (injection sequence), turning the engine with each cylinder piston at top dead center on compression stroke.

Firing order 1 9 6 14 2 10 4 12 8 16 3 11 7 15 5 13

(Example): After checking and adjusting the cylinder No.1, turn the engine 60° and check and adjust the cylinder No. 12.


Cylinder No.	1	9	6	14	2	10	4	12	8	16	3	11	7	15	5	13
Timing (°)	0	60	90	150	180	240	270	330	360	420	450	510	540	600	630	690



Vibration damper inspection

NOTE! When installing a damper protective cover to the engine, do not use a cover enclosing the damper.

Visually check for fluid leaks, flaws, distortion, or discoloration or flaking of painted surfaces. Also check for swelling (by measuring with a scale), and fluid leaks past staked portions.




Re-tighten bolts and nuts

Re-tighten the bolts and nuts on the following components:


- * Timing gear case
- * Crankshaft pulley
- * Mounting brackets
- * Exhaust manifold
- * Turbocharger
- * Cylinder heads

Check the cylinder head bolts and re-tighten them in number sequence (1-2-3-4-5-6) if necessary. The tightening torques of the bolts and nuts can be found in technical data section of this manual.


Using the turning gear




1. Loosen the two bolts securing the shaft lock plate and remove the plate from the shaft (groove).



2. Push in the shaft all the way to the TURN position.




3. Put a socket to the hexagonal end of the shaft and turn the shaft with a ratchet handle for turning.



4. After turning the engine, pull the shaft back to the RUN position, secure the shaft with the locking device and tighten the plate bolts. Make sure the plate is secured properly.

⚠ WARNING! Before starting the engine, make sure the turning gear is in the RUN position and is locked.


Lubrication system



Checking oil level

The oil level must be within the marked range on the dipstick and must be checked daily.

⚠ IMPORTANT! The level must never be allowed to drop beneath the minimum or rise above the maximum mark on the dipstick.



Filling oil


Fill the engine with lubrication oil through the filler pipe. For oil specification refer to chapter technical data. The oil level should be within the marked area on the dipstick. After filling oil, secure filler cap.

⚠ WARNING! Lubrication oil on hot surfaces or electrical components may cause fire. Do not smoke while filling oil or when handling oil containers.

⚠ IMPORTANT! Stop the engine when filling oil.

⚠ IMPORTANT! Avoid mixing oils of different brands, additives used in the oils can cause chemical reactions that may degrade the oil performance.

⚠ IMPORTANT! The lubrication oil level must never be allowed to drop beneath the lower, or rise above the maximum, mark on the dipstick.




Filling oil in new or reconditioned engine

If your engine is new or reconditioned you should besides the actual filling of new lubrication oil also do the following:

1. Remove the rocker cover. Lubricate the valve mechanism and fill the camshaft oil bath from the cylinder head. Repeat the procedure for each cylinder.
2. Mount all the rocker covers. Refer to section Tightening torques for proper torques.

NOTE! Avoid running or cranking the engine without the rocker covers mounted.



Changing oil

Always observe the recommended oil change interval.

⚠ IMPORTANT! Only use recommended grades of oil (see chapter technical data).

1. Warm up the engine (this makes it easier to suck the oil up from the sump). Then stop the engine.

⚠ WARNING! Hot oil and hot surfaces may cause burns.

2. Connect a hose to the outlet pipe of the lubrication oil scavenging pump. Pump the oil out.

NOTE! Collect the old oil and filters and deposit in accordance with local regulations. Never dispose of old oil or oil filters overboard.

3. Change the oil filters and the by-pass filter at every oil change (please refer to section oil filters change).
4. Fill with oil to the correct level through the oil filling pipe.

5. Start the engine and allow it to idle. Check the oil pressure and make sure that there are no leaks by the filters.



⚠ WARNING! Approaching or working with a running engine is a safety risk. Be careful to avoid rotating components and hot surfaces.

6. Stop the engine. Wait a few minutes before you check the oil level. Top up if necessary.


Changing oil filter

Each filter has its own shut off valve located on the housing where the filter is mounted.

- ⚠ **WARNING!** Always keep all four filters in operation when the engine is running.
- ⚠ **WARNING!** Reduce the engine speed to idle when changing oil filters on a running engine.
- ⚠ **WARNING!** Never put more than one oil filter offline at the time.




1. Remove the cover from the switch valve on the filter that are to be replaced.
2. Cut off the oil flow through the selected filter by turning the setting valve in position B.
3. Unscrew the oil filter using a filter wrench. Discard the filter.



NOTE! Place a container underneath the filter to avoid oil spill when removing.

4. Lightly oil the new filter's rubber gasket and check its mating surface on the mounting.
5. Mount the new filter by hand until the gasket is in contact with the sealing surface. Then tighten the filter a further approximately 3/4 of a turn using a filter wrench.
6. Put the filter on-line by turning the valve in position A.
7. Replace the filter switch cover at its original position and retighten the two connection bolts.
8. Repeat the described procedure for the other oil filters.

NOTE! After a lubrication oil filter change, open the discarded filter and check for metal parts.



Changing hydraulic governor oil filter

1. Stop the engine.
2. Place a drip pan under the governor oil filter.
3. Loosen the screw holding the pipe connecting the oil filter and the governor (1).
4. Remove the pipe (2).
5. Open the air vent plug (3) so that the rest of the remaining oil flows into the oil drip pan.
6. Remove the center bolt (4), remove the old filter and mount a new.
7. Remove the air vent plug and fill the filter housing with new oil.
8. Tighten the air vent plug.

Fuel system

- ⚠ WARNING!** Always protect your hands when carrying out leak detection. Escaping fluids under pressure can pierce bodily tissue and cause serious injury. Risk of blood poisoning. Always cover any electric component if it is located under the fuel filter. Otherwise it might be damaged by fuel spills.
- ⚠ WARNING!** Work performed on the fuel system must be done on a cold engine. Fuel leaks and spills on hot surfaces or electrical components can cause fires.


Bleeding the fuel system

- ⚠ IMPORTANT!** Place a drip pan under the fuel filters.


Prime the fuel filters and fuel injection pump in the following sequence:

Bleeding the fuel filter


1. Put the fuel filter switching cock in the left filter bleed position and loosen the left air vent plug.




2. Turn the priming pump plunger counterclockwise to unlock the mechanism.




3. Move the plunger up and down until the fuel flows free of bubbles from air and tighten the air vent plug.




4. Put the fuel filter switching cock in the neutral position and repeat the above-described procedure for the other fuel filter.






Bleeding the fuel injection pumps

1. Loosen the air vent cock on the fuel injection pump about 1.5 turns.



2. Move the priming pump cap up and down to start the flow of fuel through the system.
3. When the fuel coming out of the air vent cock shows no visible bubbles, lock the priming pump cap while holding it down. Then tighten the air vent cock.

Be sure to lock the priming pump cap before tightening the air vent plugs and cock. If this is not done the cap does not return to the original position due to the pressure in the priming pump.



4. Tighten the priming pump cap by hand until the tightening force increases, normally this occurs after turning it approximately 70 to 90 degrees. Mark this position on the priming pump cap to make item 5 work more easily.
5. Tighten the priming pump cap an additional 120 to 150 degrees using a wrench.

NOTE! Be sure to bleed both injection pumps.

6. Clean the engine from spoiled fuel to prevent fire and pollution of the environment.


⚠ IMPORTANT! If the priming pump cap is tightened too much (more than 240 degrees in total), the top of the priming pump can be damaged.

⚠ IMPORTANT! Looseness of the priming pump cap in combination with engine vibration may cause engine failure and damage to the installation.


Changing the fuel filter

Switchable fuel filters can be changed while the engine is running as the flow of fuel can be cut off to one filter at a time.


⚠ WARNING! Working on or approaching a running engine is a safety hazard. Beware of rotating parts and hot surfaces.




- A. Right Filter bleed position
- B. Right Filter change position
- C. Neutral position
- D. Left Filter change position
- E. Left Filter bleed position




1. Place a drip pan under the fuel filter.
2. Put the fuel filter switching cock in the Left filter change position and unscrew the left-hand fuel filter. Use a filter wrench if necessary.
3. Coat the gasket of a new filter with clean diesel fuel.
4. Install the new filter in the filter bracket by hand. When the gasket contacts the base, tighten 1/2 to 3/4 of a turn more.



5. Put the fuel filter switching cock in the Left filter bleed position and loosen the left air vent plug until the fuel running out is free from air. Close the air vent.
6. Put the fuel filter switching cock in the neutral position and repeat the above described procedure for the other fuel filter.





Changing fuel injector nozzle

⚠ IMPORTANT! Cover all open fuel injection pipes, fuel intake openings and the fuel injection nozzle to keep dirt out

Removing the fuel injector

1. Remove the rocker cover.
2. Remove the clamp from the fuel injection pipe.
3. Remove the fuel injection pipe from the fuel injector.
4. Remove the injector inlet connector.
5. Remove the injector gland nut to take off the nozzle gland.
6. Pull out the fuel injector using the special tool.

Removing the nozzle

⚠ IMPORTANT! The injector nozzle is very delicate, handle with care.

1. Fasten the fuel injector in a vice.
2. Remove the set screw and the cap nut.
3. Loosen the adjusting screw with a screw driver until it can be loosened by hand.

Note! This operation is required to release spring pressure applied to the nozzle. When spring pressure is applied, it is hard to loosen the retaining nut.


4. Remove the retaining nut and remove the nozzle.



Cleaning the nozzle

⚠ IMPORTANT! Do not mix up the pairing of needle valve and body when cleaning more than one at a time.

1. Dip the nozzle in clean fuel oil and disassemble the needle valve.
2. Clean the injection holes.
3. After cleaning, carefully insert the needle valve into the body in clean oil.




Installing the nozzle

1. Install the nozzle according to the pin on the nozzle.
2. Tighten the retaining nut by applying the specified torque 177 to 196 Nm (18 to 20kpm) [130 to 145 lbf.ft]. (Apply oil to the nut.)

⚠ IMPORTANT! Do not use Moly Disulfide.

3. Adjust the nozzle opening pressure and check spray conditions.




Fuel injection pressure

⚠ WARNING! Do not allow the fuel injected from a nozzle to contact the skin or body when inspecting the nozzle using a nozzle tester. The fuel injected from the nozzle has an extremely high pressure, strong enough to penetrate skin and causing serious injury.

1. Attach the fuel injection nozzle to the nozzle tester.
2. While watching the pressure gage of the nozzle tester, push the handle down slowly.

⚠ IMPORTANT! If fuel drips from the end of the nozzle it must be replaced.

3. When the handle is being pressed down, the fuel is injected, and the needle of the pressure gage decreases suddenly. The pressure value indicated at this point is the fuel injection start pressure.



Nozzle opening pressure

34.32 MPa (350 kp/cm²) [4979 psi]


Fuel injection nozzle spray pattern

Check spray conditions when checking fuel injection pressure. Good spray conditions are as follows:

- Fuel is injected from all nozzle holes.
- The fuel is sprayed in a conical shape.
- No big particles but fine ones.
- No oil drip is left after injection.


If the nozzle fails to spray fuel properly, replace with a new one.

NOTE! Fuel injection pressure and nozzle spray pattern check intervals may be extended in steps of 250 hours if they are ok at 1000 hrs.




Adjusting the fuel injection pressure

1. To adjust injection pressure, remove the set screw from the nozzle holder, loosen the cap nut, and then turn the adjusting screw. To increase the injection pressure, tighten the screw. To decrease the injection pressure, loosen the screw.
2. When the pressure meets the standard value, tighten the cap nut to 69 - 78 Nm (7 - 8 kpm) [51 - 58 lbf.ft].
3. Tighten the set screw to 34 - 44 Nm (3.5 - 4.5 kpm) [25 - 33 lbf.ft].




Fuel injector installation

1. Remove the injector inlet connector from the fuel injection nozzle.
2. Attach three O-rings to the injector and grease them.
3. Apply a small amount of grease to a gasket and attach to the injector.
4. Insert the injector into the cylinder head aligning its inlet connector hole to the connector hole in the head.
5. Attach the injector inlet connector to the injector by applying the specified torque, 64 to 74 Nm (6,5 to 7,5 kpm) [47 to 54 lbf].
6. Attach the injector gland and tighten the nut at the specified torque (98 N -m (10 kgf m) [72 lbf]).
7. Attach the injection pipe and fuel leak-off pipe.
8. Before mounting the rocker cover, operate the engine at approx. 850 min-' and check for any fuel leakage from each joint. Install the rocker cover after confirming no fuel leakage.




Injection timing inspection

The injection timing is indicated on the caution plate attached to the No. 1 rocker cover. Check it before inspection. Bring the piston for No. 1 cylinder to top dead center on compression stroke as follows:




1. Turn the engine in the normal direction to align the timing mark [1.6] on the damper with the pointer as shown.
2. Remove the No. 1 rocker cover and make sure the inlet and exhaust valves for No. 1 cylinder have some clearance. If these valves have no clearance, turn the engine once again to align the timing mark [1.6].


NOTE! Do not confuse the No. 1 cylinder with No. 6. When the piston for the No. 1 cylinder is in the above-mentioned position, its inlet and exhaust valve are seated, presenting some clearance.



3. Turn back the engine approximately 60 degrees, and turn it in the normal direction slowly until the specified timing (indicated on the caution plate) aligns with the pointer.



4. To ensure proper injection timing, make sure that the timing mark (B) on the coupling flywheel aligns with the pointer (A) on the fuel injection pump.



Adjusting fuel injection timing

1. Make sure the timing mark (indicated on the caution plate) is aligned with the pointer, with the piston for the cylinder at top dead center on compression stroke.
2. Loosen the bolts (C) for the fuel injection pump coupling.
3. Turn the coupling flywheel until the timing mark (B) on the coupling flywheel aligns with the pointer (A) on the fuel injection pump.
4. Tighten the one nut for fuel injection pump coupling. Turn the engine to tighten the other side nut.
5. Turn the engine (two turns) to recheck the injection timing for verification.

Fuel control

Fuel control link joints inspection

Check the ball joints for play. If there is more than 0.1 mm [0.004in.] play, replace the ball joints with new ones.


⚠ WARNING! In case of a control link having ball joints that is an integral part of the link, change the link as an assembly.


Injection pump control rack operation

Move the stop lever back and forth a few times and find out if the control rack can be operated smoothly.

⚠ WARNING! If the rack sticks this must be fixed before starting the engine.

⚠ WARNING! Never try to control the engine rpm by moving the manual stop control lever in the opposite direction of the arrow. This can result in serious harm of the installation.





Twin fuel pre-filter/water separator


⚠ WARNING! Working on or approaching a running engine is a safety hazard. Beware of rotating parts and hot surfaces.

The dual filter is equipped with a pressure gauge (1) indicating when it is time to change the filter insert. The filter inserts must be changed according to the maintenance schedule recommendations or earlier if the pressure gauge indicates a vacuum of 6–10 inHg at idling speed or 16–20 inHg at full engine speed/load.

Draining the fuel filter

Place a receptacle under the filter. Drain off water and contaminants through the plug (D) in the bottom of the bowl.

⚠ IMPORTANT! Do not drain until a few hours after stopping.




Changing the filter elements



The dual filter inserts can be changed while the engine is running as the flow of fuel can be cut off to one filter container at a time.

The flow of the fuel is governed by putting the knob (1) in the following positions:

- A: Normal running (both filters connected).
- B: Left filter insert can be changed.
- C: Right filter insert can be changed.
- D: Both filters turned off.



Close the fuel cocks on the tank or cut off the flow of fuel with the knob (1) for the filter insert to change if running.



⚠ WARNING! Working on or approaching a running engine is a safety hazard. Beware of rotating parts and hot surfaces.

1. Place a receptacle under the filter.
2. Undo the T-bolt (2) and remove the cover (3).
3. Take out the insert carefully while turning it.
4. Drain off water and contaminants through the drain plug (4).
5. Fit a new filter insert and fill the container with clean fuel.

⚠ IMPORTANT! Cleanliness! No contaminants must be allowed in the fuel system.

6. Change the gasket on the cover and the O-ring on the T-bolt. Moisten the gasket and O-ring with fuel before assembling.
7. Fit the cover and tighten it by hand.
8. Wipe off any fuel from the heat shield.
9. Dual filter: Change the other filter insert in the same way.
10. Open the fuel cocks and put the knob in position for normal running. Make sure there are no leaks.


Air inlet and exhaust systems

Turbocharger inspection

⚠ WARNING! Check the turbocharger only when the engine is cool and the compressor wheel is not running.

Check shaft play, take a hold of the compressor wheel nut and turn the wheel to feel rattle and listen for abnormal noise. Replace the bearings if the wheel is noisy or rattles.

NOTE! Also check the turbocharger when the exhaust color is abnormal.




Cleaning the air cooler

Remove the air cooler, and blow compressed air in the direction opposite to normal air flow.

Checking air cooler drain pipe

Make sure the drain from the air cooler is not clogged.




Washing the air inlet silencer filter

Remove dust from the air filters on the suction side of the turbocharger silencers. Be sure to keep the air filters clean to ensure optimum engine performance.

1. Remove the air filter from the silencer, and hand-wash with a mild detergent.
2. Rinse the air filter with clean water.
3. After drying thoroughly, reinstall the air filter in the silencer.
4. Repeat the procedure on the other airfilter.







NOTE! If the air filter is damaged it must be replaced.



Cooling system, general

The freshwater system is the internal cooling system of the engine. It is a closed system and shall always be filled with coolant that protects the engine from internal corrosion and frost damage if the climate requires it. Anti-corrosive additives become less efficient with age and the coolant must therefore be changed in accordance with the recommendations in the maintenance schedule.


The rawwater system can be connected to seawater or a central cooling system.

-  **WARNING!** Never open the pressure cap or drain the cooling system when the engine is warm. Steam or hot fluid may spurt out.
-  **WARNING!** The coolant is dangerous to your health and an environmental hazard. Handle coolant with care and dispose of old coolant in accordance with local regulations.
-  **IMPORTANT!** For coolant specification, refer to chapter “Technical data: Coolant specification” in the back of this manual.
-  **IMPORTANT!** Check the coolant level on a cold stationary engine.
-  **IMPORTANT!** Coolant to be added should have the same concentration as the coolant in the engine. Do not add plain water.
-  **IMPORTANT!** Certain parts of the system are made of light alloy. Chemical additives must therefore not be used when cleaning the system.


Cooling system D49A/D65A MS HE

The thermostat regulated freshwater system is cooling the lubrication oil coolers, the engine and the charge air coolers. An engine driven cooling water pump circulates the coolant through the heat exchanger and through the engine.

The rawwater system cools the internal cooling system in an engine mounted heat exchanger.




Freshwater drain points (D)




Cooling system D49A/D65A MS KC (1 circuit)

The engine cooling water is cooled by, e.g, a box cooler, a grid cooler, or any other external heat exchanger. The same coolant (fresh water) is cooling the complete engine.




Freshwater drain points (D)




Cooling system D49A/D65A MT HE

The thermostat regulated freshwater system is cooling the engine and the lubrication oil coolers. An engine mounted freshwater pump circulates the coolant through the heat exchanger and through the engine.

The rawwater system is cooling the charge air and the coolant in the freshwater cooling system. The rawwater circuit is designed for seawater or for connection to a central cooling system.




Freshwater drain points (D)




Cooling system D49A/D65A MT KC (2 circuit)

The thermostat regulated freshwater system is cooling the engine and the lubrication oil cooler. The engine cooling water is cooled by, e.g. a box cooler, a grid cooler, or any other external heat exchanger.


The rawwater system is cooling the charge air.



Freshwater drain points (D)



Freshwater system



Checking the coolant level

MS engines

Make sure the level is between the MIN and MAX marks. If there are no marks, the coolant level should be approximately 5 cm below the top of the filler cap. For coolant specification, refer to chapter "technical data" in the back of this manual.

MT engines

The cooling water level (A) should be approximately 5mm below the top of the side glass on a cold engine.

Filling the coolant

Topping up

Fill the freshwater system with coolant to the correct level through the filler opening in the expansion tank. For correct coolant level, refer to section "coolant level check". Fill slowly so that the evacuated air is able to pass the filler opening.


Filling when the system is empty

1. Open the air ventilation cocks and close the coolant drain cocks.
2. Make sure that systems connected to the cooling system also are ventilated, e.g. heater, water heater.
3. Fill the freshwater system with coolant to the correct level through the filler opening in the expansion tank. For correct level, refer to section "Checking the coolant level". Fill slowly letting air bleed from the ventilation cocks and the filler opening. When air-free coolant flows out, close the ventilation cocks.
4. To bleed the system, open the air vent cock on the water pump and crank the engine for 10 seconds while holding the emergency stop lever in stop position. Repeat several times at one minute intervals.
5. Close the air vent. Check the coolant level and top up if needed.

⚠ IMPORTANT! Make sure that the engine is filled with lubrication oil before starting or cranking the engine.

⚠ IMPORTANT! The engine must not be started before the system has been bled and topped up.

6. Start the engine and run it under light load until the thermostat valve opening temperature is reached.
7. Check air vents for leaks.
8. Stop the engine and allow it to cool. Check the coolant level in the expansion tank and top up if needed.




Draining the coolant

1. Remove the filler cap on the expansion tank.
2. Open the air vent cocks and then drain the coolant from the drain cocks.

⚠ IMPORTANT! Check that the coolant really drains. Deposits may need to be removed from inside the drain plugs/taps.


3. Drain all systems connected to the freshwater system, e.g. heater, water heater, etc.
4. Close all drainage points.



Flushing the freshwater system

The system should be flushed before changing coolant to avoid inferior cooling performance due to deposits in the cooling system.

1. Drain the coolant as described earlier.
2. Insert a hose into the filler opening and flush with fresh water.
3. Flush until the water running out of the drainage points is clean.
4. Close all drainage points when the flushing water has run out.
5. Fill with coolant. See section coolant filling when empty.



Rawwater system

The rawwater system is the engine's external cooling system. It cools the internal cooling system in an engine mounted or externally mounted heat exchanger. The system is protected against galvanic corrosion by zinc anodes located in the heat exchanger.


Keep the engine room heated or use an antifreeze coolant in the rawwater system. Otherwise the rawwater system must be drained when there is a risk of freezing in cold weather.

⚠ WARNING! The rawwater cocks and/or the cocks of the external cooling system must be closed before commencing work on the rawwater system. This due to the risk of sea water or water from the central cooling system entering the vessel.

Draining the rawwater system

1. Close the rawwater in- and outlet cocks.
2. Drain the coolant from the external cooling system.

⚠ IMPORTANT! Check that the coolant really drains. Deposits may need to be removed from inside the drain plugs/taps.



Checking/Changing zinc anodes

Note! Zinc anodes are consumed differently, depending on the marine environment.

1. Drain the external cooling water as described in the chapter draining the rawwater system.
2. Unscrew the zinc anodes from the heat exchanger.
3. Change the anode if less than 50% remains. If not, clean the anode with emery cloth to remove the layer of oxide.


⚠ IMPORTANT! Do not use a wire brush or other metal tool for cleaning as this may decrease the galvanic protection.

4. Fit the zinc anodes. Make sure there is good contact between the anode and the metal goods.
5. Open the rawwater cocks before starting the engine
6. Check the installation and make sure there are no leaks.

Checking/Changing rawwater filter

If the vessel is equipped with a rawwater filter refer to the maintenance description supplied by the supplier of the filter.


NOTE! If the water wherein the vessel operates is severely polluted, contains large amounts of seaweed, etc., the filter must be checked more often than is specified. The filter can otherwise become clogged and the engine overheated.



Checking/Changing rawwater pump impeller

⚠ IMPORTANT! Always keep a spare impeller and gasket in store aboard the ship.

1. Drain the external cooling water as described in the chapter draining the rawwater system.
2. Remove the pump end cover and the impeller.
3. Inspect the impeller. Change the impeller if there are any visible cracks or other defects.
4. Clean the inside of the housing. Lubricate the pump housing and the inside of the cover with water-resistant grease (non-aggressive on rubber).
5. Push the impeller into position while rotating it in the normal operating direction.
6. Fit the cover with a new gasket.
7. Close the drain cocks.
8. Open the rawwater cocks.



Cleaning the heat exchanger

Clean if there are signs of clogging, a gradual increase in engine temperature or high rawwater pressure. Check/clean the rawwater filter first. Also check for other damages on the heat exchanger.

1. Drain the external cooling water as described in the chapter draining the rawwater system.
2. Detach the pipe connections from the heat exchanger.
3. Remove both covers from the heat exchanger
4. Clean the heat exchanger insert pipe using suitable brushes while flushing through the pipe with water
5. Refit the heat exchanger element and mound the covers.
6. Connect the pipe connections to the heat exchanger. Check gaskets and change if necessary.
7. Open the rawwater cocks. Fill the freshwater system.
8. Start the engine and make sure the rawwater system is not leaking.


Electrical system

Protective devices inspection

Make sure that the instruments and the alarm functions of the engine control system work properly.

Checking the electrical wiring

Check for loose or damaged electrical cables. Damaged cables must be replaced.




Starter motor inspection

1. Visually inspect the starter motors for damages and dirt build-up. Repair and clean if needed.
2. Check the pinion for shifting and meshing action. If the starters has a defect, consult your dealer.
3. Check if the clutch of the starter motors operates smoothly.

Alternator inspection

1. Inspect the alternator on functionality and clean it if needed.
2. Remove the V-belt from the alternator. Turn the alternator pulley by hand to check the rotation. If the alternator has a defect, consult your dealer.



Checking/Adjusting/Changing the drive belts


⚠ WARNING! Stop the engine before commencing maintenance work.

Check belt tension and condition regularly. If the belt is too tight it can damage bearings and if it is too loose it may slip. Check and adjust after operation when the belt is warm.

The belt is correctly tensioned when it can be depressed approximately 10 mm between the pulleys. Clean the belt grooves before fitting a new belt.

⚠ IMPORTANT! Always change a belt that appears worn or is cracked (belts working in pairs must be replaced together).

⚠ IMPORTANT! Always keep the belts clear of oil or grease. Oil or grease can cause the belts to slip, which might shorten belt life.



Inhibiting

General

To prevent the engine and other equipment from being harmed during long (2 months or more) periods out of service, it must be conserved. It is of utmost importance that the conservation is performed correctly. Therefore we have compiled a checklist of the most important points. Before taking the engine out of service for long periods, it should be checked by a Volvo Penta dealer for possible needed overhaul or repairs of the engine and other equipment.

⚠ WARNING! Read the chapter "Maintenance" thoroughly before starting any maintenance work. It contains directions for performing maintenance in a safe and correct manner. Certain preservatives are flammable. Some are also dangerous to inhale. Provide good ventilation. Use a protective mask.

⚠ IMPORTANT! The following must be considered when cleaning with a high-pressure water jet: Never point high-pressure water jets directly at seals, rubber hoses or electrical components. Never use the high-pressure function when washing the engine.

Preparation

1. Drain the lubrication oil from the engine and fill it with new lubrication oil or conserving oil.

⚠ IMPORTANT! Post a warning sign on the engine that the conserving oil must be replaced with the specified lubrication oil before starting the engine again.

2. Run the engine on idling speed on a mixture of 70% fuel and 30% lubrication oil until the complete fuel system is filled with the mixture, then stop the engine (If possible, top up the fuel tank to avoid condensation).
3. When the engine is coming to a stop but is still rotating, spray volatile rust preservative in the air intake and exhaust system. This to prevent rust on the intake system.
4. Apply a coat of rust preservative to the exposed, machined surfaces of the engine.
5. Cover breather, air inlet and exhaust openings with tape.
6. Loosen the alternator and water pump drive belts.
7. Tape the starter and alternator terminals and cover the starter and alternator with a polyethylene sheet. Put a desiccant inside the covering.

⚠ IMPORTANT! Never use vinyl sheets for covering. This can result in condensation and harm the installation

8. Remove the batteries and charge them. Clean the terminal posts and coat them with acid free Vaseline. Keep the batteries in a dry, cool place.
9. Cover the engine for weather protection.

⚠ IMPORTANT! Store the engine in a well-ventilated room.

⚠ IMPORTANT! It is not necessary to drain the coolant because it contains coolant conditioner.

Care during storage

Recharge the battery at least once a month.

⚠ IMPORTANT! During longer periods out of operation, the preparations must be repeated every 12 months.

Return the engine to service

1. Remove the covering from the engine.
2. Connect well-charged batteries to the engine.
3. Remove the covering from the starter and alternator.
4. Adjust the alternator and water pump drive belts.
5. Remove all coverings and tapings.
6. Drain the rust preservative from the engine and fill the engine with recommended engine oil.
7. Fill the fuel tank and prime the fuel system.
8. Check under and around the engine for such items as loose or missing bolts, oil, fuel or coolant leaks and repair if needed.
9. Remove the rocker covers and lubricate the valve mechanism.
10. Crank the engine three times, 10 seconds each time, at intervals of one minute, with the fuel supply shut off, to make sure the oil pressure rises properly.
12. Start the engine.
13. Allow the engine to warm up at low idle.
14. When the engine has run long enough to warm up apply the load and bring it to operating speed.

Storage of engine in operating condition

Service the engine once a month in the following manner:

1. Crank the engine two times, for 10 seconds each time, with the starter at intervals of 30 seconds, with the fuel supply shut off.
2. Start and run the engine under no-load condition for 5 to 10 minutes.

⚠ IMPORTANT! If the engine is fitted with a wet exhaust system and the exhaust is situated below the water line the above has to be performed twice a week (if the exhaust is situated above the water line, once a week is enough).

Troubleshooting

A number of symptoms and possible causes for engine disturbances are described in the table below. If faults or hitches arise that you cannot solve alone, you must always get in touch with your Volvo Penta dealer.

NOTE! Dust and foreign particles are the most common cause of excessive wear of parts. When disassembling a component, take measures to prevent dust and foreign particles from entering it.

⚠ WARNING! Read the safety directions for maintenance and service in the chapter "Safety information" before starting any work.

⚠ IMPORTANT! Handle parts carefully. Only use original Volvo Penta spare parts.

Symptoms and possible causes	
Starter motor does not rotate when cranking	1,2,3,4,5,6
Starter motor rotates slowly when cranking	1,2,3,22,48,49
Engine does not start	,8,9,10,11,12,13,14,15,20,21,23,24,28,50,58
Engine is difficult to start	8,9,10,11,12,13,14,15,20,21,23,24,28,50,51
Engine starts but stops again	8,9,10,11,12,13,14,15,20,21,23,24,28,50,51 52,53
Engine does not reach correct operating speed	8,9,10,11,12,13,14,15,18,19,20,21,22, 23,24,25,26,27,28,33,36,53,58
Engine runs unevenly	8,9,10,11,12,13,14,15,16,17,23,24,28,29 51,58
Engine knocks	21,29,52
Engine vibrates	9,17,23,33,34
Engine can not be stopped	2,3,4,6,54
High fuel consumption	13,15,17,19,20,21,25,26,28,30,33
Black or dark gray exhaust smoke	13,15,17,18,19,20,21,28,30
Blue or white exhaust smoke	17,19,20,21,22,30,33,43,44,51,59
High lubrication oil consumption	22,32,33,34,44
Lubrication oil pressure too low	22,31,35,45,46
Coolant temperature too high	26,38,39,40,41,42,43,55
Coolant temperature too low	43
No charge or poor charge	2,3,47,56,57

- | | | |
|--|--|---|
| 1. Defective starter | 21. Improper fuel oil | 42. Defective cooling water pump |
| 2. Flat batteries | 22. Improper lubrication oil | 43. Defective/wrong thermostat |
| 3. Poor contact/broken cables | 23. Air in fuel system | 44. Too high lubrication oil level |
| 4. Main switch turned off | 24. Water/contamination in fuel | 45. Defective lubrication oil pump |
| 5. Control lever not in neutral/control position not activated | 25. Boat abnormally loaded | 46. Defective relief valve |
| 6. A fuse/circuit breaker has blown/tripped | 26. Fouled hull/propeller | 47. Alternator drive belt slips |
| 7. Lack of fuel | 27. Engine speed control wrongly adjusted | 48. Clutch is engaged |
| 8. Blocked fuel filter | 28. Insufficient air supply | 49. Defective bearings or abnormal cylinder friction |
| 9. Defective fuel filter | 29. Too high coolant temperature | 50. Fuel supply pump strainer blocked |
| 10. Blocked fuel pipes | 30. Too low coolant temperature | 51. Very cold engine and lubrication oil |
| 11. Defective fuel pipes | 31. Too low lubrication oil level | 52. Heavy initial load |
| 12. Blocked fuel supply pump | 32. Lubrication oil leakage | 53. Propeller/propeller shaft blocked |
| 13. Defective fuel supply pump | 33. Worn cylinder liners and/or piston rings | 54. Engine consume lubrication oil or combustible gas |
| 14. Blocked fuel injection pump | 34. Worn valve stem seals | 55. Cylinder liner have scalings or such that reduce cooling effect |
| 15. Defective fuel injection pump | 35. Blocked lubrication oil filter | 56. Alternator/Rectifier broken |
| 16. Blocked fuel injection nozzles | 36. Defective/wrong propeller | 57. Faulty governor |
| 17. Defective fuel injection nozzles | 37. Faulty engine mounting | 58. Broken piston |
| 18. Incorrect valve clearance | 38. Too low coolant level | |
| 19. Incorrect fuel injection timing | 39. Air in fresh water system | |
| 20. Low compression pressure | 40. Blocked sea water inlet/pipe/filter | |
| | 41. Circulation pump drive belt slips | |

Technical Data

D65A MS

General

Number of cylinders	16	
Displacement	65,37 liters (3989 in ³)	
Nominal idling speed	not available	
Low idling speed	625 ±25 rpm	
High idling speed	not available [rating 1]	not available [rating 2]
Valve clearance*	0,6 mm (0,024") [inlet]	0,8 mm (0,031") [outlet]
Compression pressure at starter motor speed (120 rpm)	not available	
Weight, engine with heat exchanger, without reverse gear or clutch, approx.	6220 kg (13715 lbs)	

Exhaust temperatures: **1170 kW Rating 1**

1008 r/min.	353°C (667°F)
1270 r/min.	473°C (883°F)
1454 r/min.	493°C (919°F)
1600 r/min.	492°C (918°F)

Exhaust temperatures: **1290 kW Rating 2**

1039 r/min.	372°C (702°F)
1310 r/min.	450°C (842°F)
1500 r/min.	457°C (855°F)
1650 r/min.	457°C (855°F)

* Applies to cold engine.

Lubricating system

Oil capacity, approx.	Including oil filters
No engine inclination	290 liters (76,6 US gals)
volume difference min. –max.	66 liters (17,5 US gals)
Oil pressure, hot engine:	
at operating speed	0,50-0,64 MPa (71-93 psi)
at idling speed	min.0,20-0,30 MPa (29-43 psi)

Cooling system

Freshwater system capacity including heat exchanger, approx.	170 liters (44,9 US gals)
--	---------------------------

Electrical system

System voltage	24V
AC generator:	
voltage/max. amperage	24V/35A
output, approx.	840W

Battery electrolyte density at +25°C (77°F):

fully charged battery	1,28 g/cm ³ = 0,0462 lb/in ³ (1,24 g/cm ³ = 0,0448 lb/in ³)*
battery recharged at	1,24 g/cm ³ = 0,0448 lb/in ³ (1,20 g/cm ³ = 0,0434 lb/in ³)*

* **Note.** Applies to batteries with tropical acid.

D65A MT

General

Number of cylinders	16	
Displacement	65,37 liters (3989 in ³)	
Nominal idling speed	not available	
Low idling speed	625 ±25 rpm	
High idling speed	not available [rating 1]	not available [rating 2]
Valve clearance*	0,6 mm (0,024") [inlet]	0,8 mm (0,031") [outlet]
Compression pressure at starter motor speed (120 rpm)	not available	
Weight, engine with heat exchanger, without reverse gear or clutch, approx.	6400 kg (14112 lbs)	

Exhaust temperatures:

1250 kW Rating 1

1008 r/min.	333°C (631°F)
1270 r/min.	421°C (790°F)
1454 r/min.	443°C (829°F)
1600 r/min.	455°C (851°F)

Exhaust temperatures:

1380 kW Rating 2

1039 r/min.	320°C (608°F)
1310 r/min.	400°C (752°F)
1500 r/min.	440°C (824°F)
1650 r/min.	450°C (842°F)

* Applies to cold engine.

Lubricating system

Oil capacity, approx.

Including oil filters

No engine inclination	290 liters (76,6 US gals)
volume difference min. –max.	66 liters (17,5 US gals)

Oil pressure, hot engine:

at operating speed	0,50-0,64 MPa (71-93 psi)
at idling speed	min.0,20-0,30 MPa (29-43 psi)

Cooling system

Freshwater system capacity

including heat exchanger, approx.	280 liters (74,0 US gals)
--	---------------------------

Electrical system

System voltage	24V
----------------------	-----

AC generator:

voltage/max. amperage	24V/35A
output, approx.	840W

Battery electrolyte density at +25°C (77°F):

fully charged battery	1,28 g/cm ³ = 0,0462 lb/in ³ (1,24 g/cm ³ = 0,0448 lb/in ³)*
battery recharged at	1,24 g/cm ³ = 0,0448 lb/in ³ (1,20 g/cm ³ = 0,0434 lb/in ³)*

* **Note.** Applies to batteries with tropical acid.

Fuel specification

Fuel must comply with national and international standards at the least, e.g.:

JIS KK 2204	Type1, Type2, Type3
ASTM, D975	No.1-D, No.2-D
BS2869	Class-A1, Class-A2
DIN51601	Diesel-Fuel
ISO8217	DMX-Class

Note! It is necessary to use a fuel that has a pour point suitable for ambient temperature during the operation of the engine. Consult the supplier to select the right type.

Property	Use limit
Flash point	As stipulated by regulation
First distillation point	170°C (338°F) or more
90% distillation point	330 to 380°C (626 to 716°F)
Pour point	6°C (10.8°F) below ambient temperature
Cloud point	Below ambient temperature
Carbon residue (10% residue oil)	0.4 weight % or lower
Cetan number	45 or more
Cetan index (new)	45 or more
Kinematic viscosity	2.0 mm ² /S or more [30°C (86°F)]
	8.0 mm ² /S or lower [50°C (122°F)]
	10.5 mm ² /S or lower [40°C (104°F)]
	16.0 mm ² /S or lower [30°C (86°F)]
Sulfur content	0.2 weight % or lower
Water and sediment	0.1 volume % or lower
Ash	0.03 weight % or lower
Copper plate corrosion (100°C)[212°F], 3h	No. 3 or lower
Specific gravity (15°C/4°C [59°F/39°F])	0.83 to 0.87
Coking test	Not carbonized 100% at 250°C (482°F)
Aromatics content	38 weight % or lower
Particulate contaminant	5.0 mg/liter or lower
Asphaltene	0.1 weight % or lower

Lubrication oil specification

Recommended types of engine oil


Use lubrication oil that meets Class CF standard (recommended engine oil). Class CE and CF-4 engine oils are designed for diesel fuel with a sulfur content of less than 0,5% and less than 0,2%, respectively. Since the sulfur content of most Class-A diesel fuel exceeds 0,5%, do not use class CE or CF-4 engine oil when using class-A diesel fuel

⚠ Important! Use of improper or inferior oil can cause excessive wear of bearings and moving parts, thus shortening the engine life. It can also result in sticking of piston rings and seizing of pistons in the cylinders, thus causing major damage.

Selection of oil viscosity


Use the following chart to select appropriate oil viscosity according to the ambient temperature. Recommended oil viscosity is SAE 15W-40 for all seasons.

⚠ Important! Excessively high oil viscosity causes power loss and higher oil temperature, while excessively low oil viscosity results in inadequate lubrication and leakage of combustion gas with increased wear and reduced output as a result.



Coolant specification

Always use Volvo Penta Coolant in the freshwater cooling circuit. Volvo Penta Coolant acts both as anti-freeze agent and provides corrosion protection for the metal parts of the cooling system. Future claims might be rejected should Coolant 90 not have been used.

 **Important!** Mixing other types of concentrated coolant with Volvo Penta Coolant, may decrease corrosion protection and may damage the engine or block the cooling system.


Water

Always use clean water that complies with the requirements in ASTM D4985 X1.1. If these requirements are not complied with, corrosion may occur, which would result in impaired cooling performance.

Total fixed particle content	< 340 ppm
Total hardness	< 9,5 °dH
Chloride	< 40 ppm
Sulphate	< 100 ppm
pH value	< 5,5 – 9
Silica	< 20 mg SiO ₂ /l
Iron	< 0.10 ppm
Manganese	< 0.05 ppm
Conductivity	< 500 iS/cm
Organic content, COD _{Mn}	<15 mg KMnO ₄ /L

Mixing ratio

The mixture of Volvo Penta Coolant and water should contain 40-55% Volvo Penta Coolant. If the coolant contains less than 40% Volvo Penta Coolant, the cooling galleries in the engine or radiator may be blocked by contamination. If the coolant contains more than 60% Volvo Penta Coolant the cooling ability of the coolant mixture is impaired, this may cause the engine to overheat. Too high concentration of Volvo Penta Coolant also impairs the frost protection.

 **Important!** The mixture of Volvo Penta Coolant and water may never contain less than 40% Volvo Penta Coolant.

Tightening torque tables

Important bolts and nuts D65A MS

Description	Thread		Torque			Notes
	Diam.xPitch (M-Thread)	Nm	kpm	lbf.ft		
Cylinder head	22 x 2,5	539	55	398	(a) (b) (c)	
Cylinder head nozzle gland (studs)	14 x 2,0	69-78	7-8	51-58		
Rocker case	12 x 1,25	108	11	80		
Rocker shaft	14 x 2,0	147	15	108		
Rocker arm lock nuts	12 x 1,25	64	6,5	47		
Bridge lock nuts	10 x 1,25	55	5,6	40		
Camshaft gear	12 x 1,25	108	11	80		
Camshaft thrust plate	12 x 1,25	59	6	43		
Main bearing caps	22 x 2,5	588	60	434	(a)	
Main bearing cap side bolts	20 x 2,5	392	40	289		
Hanger	12 x 1,25	392	40	289		
Hanger	16 x 1,5	216	22	159		
Piston cooling nozzle	12 x 1,75	34	3,5	25	(d)	
Timing gear case	16 x 1,5	255	26	188		
Rear plate	12 x 1,25	108	11	80		
Rear plate	16 x 1,5	216	22	159		
Oil pan	12 x 1,25	59	6	43		
Front mounting bracket	20 x 1,5	392	40	289		
Rear mounting bracket	20 x 1,5	392	40	289		
Connecting rod metal caps	22 x 1,5	539	55	398	(a) (e)	
Flywheel	22 x 1,5	539	55	398	(a)	
Balance weight	22 x 1,5	490	50	362		
Viscous damper	22 x 1,5	490	50	362		
Ring gears	10 x 1,25	59	6	43		
Rear idler shaft	20 x 1,25	392	40	289		
Rear idler shaft (nuts)	18 x 1,5	196	20	145		
Front gear case	12 x 1,25	59	6	43		
Front gear case	16 x 1,5	216	22	159		
Front plate	12 x 1,25	59	6	43		
Front idler shaft	12 x 1,25	108	11	80		
Front idler gear thrust plate	10 x 1,25	29	3	22		
Exhaust manifold V-clamp nuts	6 x 1,0	9	0,9	6,5		
Exhaust manifold mounting bolts	10 x 1,5	98	10	72		

(a) Wet , apply lubrication oil to the threads of the nut and bolt.

(b) 2-step tightening method.

(c) Tighten cylinder head bolts according to the angle method, tighten to 294 Nm [30 kpm; 217 lbf.ft], then tighten 60° more.

(d) Extremely important to use torque wrench in tightening the piston cooling nozzles. Failure to do so may result in excessive tightening torque, which may cause valve malfunctions that could lead to seizing of pistons due to insufficient lubrication.

(e) Tighten connecting rod caps according to the angle method, tighten to 245 Nm [25 kpm; 181 lbf.ft], then tighten 60° more.

Technical Data

Oil pump	12 x 1,25	108	11	80	
Oil pump cover	10 x 1,25	26,3-39,7	2,7-4,1	18-32	
Oil & Water pump mounting plates	12 x 1,25	59	6	43	
Bearing cover (oil & water pump)	12 x 1,25	108	11	80	
Freshwater pump	12 x 1,25	108	11	80	
Freshwater pump shaft pulley (nuts)	30 x 1,5	392	40	289	For alternator drive.
Injection pump	12 x 1,25	108	11	80	
Injection pump bracket	12 x 1,25	108	11	80	
Injection pump drive case	12 x 1,25	108	11	80	
Injection pump gear (nuts)	30 x 1,5	392	40	289	
Injection pump laminate plate	12 x 1,25	103-113	10,5-11,5	76-83	
Injection pump flywheel (nuts)	24 x 1,5	392	40	289	
Injection pump coupling shaft	14 x 1,5	167-177	17-18	123-130	Tighten the slit part.
Injection pump plunger assembly	12 x 1,25	78-83	8-8,5	58-61	
Injection pump delivery valve holder	30 x 1,5	235-255	24-26	174-188	
Injection nozzle gland (nut)	14 x 1,5	98	10	72	
Injection nozzle chip (nut)	28 x 1,5	177-196	18-20	130-145	
Nozzle holder cap nuts	14 x 1,5	69-78	7-8	51-58	
Injection nozzle set screw	10 x 1,5	34-44	3,5-4,5	25-33	
Injection nozzle inlet connector	16 x 1,5	64-74	6,5-7,5	47-54	
Injection pipes	18 x 1,5	49-69	5-7	36-51	
Fuel filter air vent plug	–	7,8-9,8	0,8-1,0	5,8-7,2	
Fuel rack control lever	8 x 1,25	25	2,5	18	(b)
Governor drivecase	12 x 1,25	108	11	80	
Starter	12 x 1,25	59	6	43	
Turbocharger compressor wheel (nut)	11 x 1,0	–	–	–	TD13(f)(g)(h)
Turbocharger V-clamp	–	7,8-9,8	0,8-1,0	5,8-7,2	TD13 (g)

(a) Wet, apply lubrication oil to the threads of the nut and bolt.

(b) 2-step tightening method.

(c) Tighten cylinder head bolts according to the angle method, tighten to 294 Nm [30 kpm; 217 lbf.ft], then tighten 60° more.

(d) Extremely important to use torque wrench in tightening the piston cooling nozzles. Failure to do so may result in excessive tightening torque, which may cause valve malfunctions that could lead to seizing of pistons due to insufficient lubrication.

(e) Tighten connecting rod caps according to the angle method, tighten to 245 Nm [25 kpm; 181 lbf.ft], then tighten 60° more.

(f) Left-handed thread.

(g) Apply Moly Disulfide to thread.

(h) Tighten the lock nut to 49 Nm [5 kpm; 36 lbf.ft] first, then loosen it completely. Retighten to 14,7 Nm [1,5 kpm; 0,8 lbf.ft], then tighten 80±3° more.

(i) Tighten the lock nut to 69 Nm [7 kpm; 51 lbf.ft] then loosen it completely. Apply Loctite No. 962T to the threads. Retighten to 9,8 Nm [1 kpm; 7,2 lbf.ft], then tighten 90±3° more.

Important bolts and nuts D65A MT

Description	Thread	Nm	Torque		Notes
	Diam.xPitch (M-Thread)		kpm	lbf.ft	
Cylinder head	22 x 2,5	539	55	398	(a) (b) (c)
Cylinder head nozzle gland (studs)	14 x 2,0	69-78	7-8	51-58	
Rocker case	12 x 1,25	108	11	80	
Rocker shaft	14 x 2,0	147	15	108	
Rocker arm lock nuts	12 x 1,25	64	6,5	47	
Bridge lock nuts	10 x 1,25	55	5,6	40	
Camshaft gear	12 x 1,25	108	11	80	
Camshaft thrust plate	12 x 1,25	59	6	43	
Main bearing caps	22 x 2,5	588	60	434	(a)
Main bearing cap side bolts	20 x 2,5	392	40	289	
Hanger	12 x 1,25	392	40	289	
Hanger	16 x 1,5	216	22	159	
Piston cooling nozzle	12 x 1,75	34	3,5	25	(d)
Timing gear case	16 x 1,5	255	26	188	
Oil pan	12 x 1,25	59	6	43	
Front mounting bracket	20 x 1,5	392	40	289	
Rear mounting bracket	20 x 1,5	392	40	289	
Connecting rod metal caps	22 x 1,5	539	55	398	(a) (e)
Flywheel	22 x 1,5	588	60	434	(a)
Balance weight	22 x 1,5	490	50	362	
Viscous damper	22 x 1,5	490	50	362	
Ring gears	10 x 1,25	59	6	43	
Rear plate	12 x 1,25	108	11	80	
Rear plate	16 x 1,5	216	22	159	
Rear idler shaft	20 x 1,25	392	40	289	
Rear idler shaft (nuts)	18 x 1,5	196	20	145	
Front gear case	12 x 1,25	59	6	43	
Front gear case	16 x 1,5	216	22	159	
Front plate	12 x 1,25	59	6	43	
Front idler shaft	12 x 1,25	108	11	80	
Front idler gear thrust plate	10 x 1,25	29	3	22	
Exhaust manifold V-clamp nuts	6 x 1,0	9	0,9	6,5	
Exhaust manifold mounting bolts	10 x 1,5	98	10	72	

(a) Wet , apply lubrication oil to the threads of the nut and bolt.

(b) 2-step tightening method,

(c) Tighten cylinder head bolts according to the angle method, tighten to 294 Nm [30 kpm; 217 lbf.ft], then tighten 60° more.

(d) Extremely important to use torque wrench in tightening the piston cooling nozzles. Failure to do so may result in excessive tightening torque, which may cause valve malfunctions that could lead to seizing of pistons due to insufficient lubrication.

(e) Tighten connecting rod caps according to the angle method, tighten to 245 Nm [25 kpm; 181 lbf.ft], then tighten 60° more.

Technical Data

Oil pump	12 x 1,25	108	11	80	
Oil pump cover	10 x 1,25	26,3-39,7	2,7-4,1	18-32	
Oil & Water pump mounting plates	12 x 1,25	59	6	43	
Bearing cover (oil & water pump)	12 x 1,25	108	11	80	
Water pump	12 x 1,25	108	11	80	
Water pump shaft pulley (nuts)	30 x 1,5	392	40	289	For alternator drive.
Rawwater pump cam (screw)	10 x 1,25	15,7-21,6	1,6-2,2	11,6-15,9	
Rawwater pump casing	8 x 1,25	7,4-9,8	0,75-1,0	5,42-7,23	
Rawwater pump cover	8 x 1,25	7,4-9,8	0,75-1,0	5,42-7,23	
Rawwater pump drive gear (nut)	24 x 3,0	191-201	19,5-20,5	141-148	
Injection pump	12 x 1,25	108	11	80	
Injection pump bracket	12 x 1,25	108	11	80	
Injection pump drive case	12 x 1,25	108	11	80	
Injection pump gear (nuts)	30 x 1,5	392	40	289	
Injection pump laminate plate	12 x 1,25	103-113	10,5-11,5	76-83	
Injection pump flywheel (nuts)	24 x 1,5	392	40	289	
Injection pump coupling shaft	14 x 1,5	167-177	17-18	123-130	Tighten the slit part.
Injection pump plunger assembly	12 x 1,25	78-83	8-8,5	58-61	
Injection pump delivery valve holder	30 x 1,5	235-255	24-26	174-188	
Injection nozzle gland (nut)	14 x 1,5	98	10	72	
Injection nozzle chip (nut)	28 x 1,5	177-196	18-20	130-145	
Nozzle holder cap nuts	14 x 1,5	69-78	7-8	51-58	
Injection nozzle set screw	10 x 1,5	34-44	3,5-4,5	25-33	
Injection nozzle inlet connector	16 x 1,5	64-74	6,5-7,5	47-54	
Injection pipes	18 x 1,5	49-69	5-7	36-51	
Fuel filter air vent plug	–	7,8-9,8	0,8-1,0	5,8-7,2	
Fuel rack control lever	8 x 1,25	25	2,5	18	(b)
Governor drivecase	12 x 1,25	108	11	80	
Starter	12 x 1,25	59	6	43	
Turbocharger compressor wheel (nut)	1/2 x 20	–	–	–	TD15UNF(f)(i)
Turbocharger turbine housing	10 x 1,5	25-28	2,6-2,9	19-21	TD15 (g)
Turbocharger V-clamp	–	9,8-10,8	1,0-1,1	7,2-8,0	TD15 (g)

(a) Wet , apply lubrication oil to the threads of the nut and bolt.

(b) 2-step tightening method.

(c) Tighten cylinder head bolts according to the angle method, tighten to 294 Nm [30 kpm; 217 lbf.ft], then tighten 60° more.

(d) Extremely important to use torque wrench in tightening the piston cooling nozzles. Failure to do so may result in excessive tightening torque, which may cause valve malfunctions that could lead to seizing of pistons due to insufficient lubrication.

(e) Tighten connecting rod caps according to the angle method, tighten to 245 Nm [25 kpm; 181 lbf.ft], then tighten 60° more.

(f) Left-handed thread.

(g) Apply Moly Disulfide to thread.

(h) Tighten the lock nut to 49 Nm [5 kpm; 36 lbf.ft] first, then loosen it completely. Retighten to 14,7 Nm [1,5 kpm; 0,8 lbf.ft], then tighten 80±3° more.

(i) Tighten the lock nut to 69 Nm [7 kpm; 51 lbf.ft] then loosen it completely. Apply Loctite No. 962T to the threads. Retighten to 9,8 Nm [1 kpm; 7,2 lbf.ft], then tighten 90±3° more.

Standard bolts and nuts

Fine threads

Thread diameter x pitch	Strength classification					
	7T			10.9		
mm [in.]	Nm	kpm	lbf.ft	Nm	kpm	lbf.ft
M10 x 1,25 [0.39 x 0.049]	33	3,4	25	60	6,1	44
M12 x 1,25 [0.47 x 0.049]	60	6,1	44	108	11,0	80
M14 x 1,5 [0.55 x 0.059]	97	9,9	72	176	17,9	129
M16 x 1,5 [0.63 x 0.059]	145	14,8	107	262	26,7	193
M18 x 1,5 [0.71 x 0.059]	210	21,4	155	378	38,5	278
M20 x 1,5 [0.79 x 0.059]	291	29,7	215	524	53,4	386
M22 x 1,5 [0.87 x 0.059]	385	39,3	284	694	70,8	512
M24 x 1,5 [0.94 x 0.059]	487	49,7	359	878	89,5	647
M27 x 3 [1.06 x 0.12]	738	75,3	544	1328	135,5	980

Coarse threads

M8 x 1,25 [0.31 x 0.049]	17	1,7	12	30	3,1	22
M10 x 1,5 [0.39 x 0.059]	32	3,3	24	58	5,9	43
M12 x 1,75 [0.47 x 0.069]	57	5,8	42	102	10,4	75
M14 x 2 [0.55 x 0.079]	93	9,5	69	167	17,0	123
M16 x 2 [0.63 x 0.079]	139	14,2	103	251	25,6	185
M18 x 2,5 [0.71 x 0.098]	194	19,8	143	350	35,7	258
M20 x 2,5 [0.79 x 0.098]	272	27,7	200	489	49,9	361
M22 x 2,5 [0.87 x 0.098]	363	37,0	268	653	66,6	482
M24 x 3 [0.94 x 0.12]	468	47,7	345	843	86,0	622
M27 x 3 [1.06 x 0.12]	686	70,0	506	1236	126,0	911

Standard eyebolts

Thread diameter x pitch	Strength classification		
	4T		
mm [in.]	Nm	kpm	lbf.ft
M8 x 1,25 [0.31 x 0.049]	8±1	0,8±0,1	5,8±0,72
M10 x 1,25 [0.39 x 0.049]	15±2	1,5±0,2	10,8±1,45
M12 x 1,25 [0.47 x 0.049]	25±3	2,5±0,3	18,1±2,17
M14 x 1,5 [0,55 x 0.059]	34±4	3,5±0,4	25,3±2,89
M16 x 1,5 [0.63 x 0.059]	44±5	4,5±0,5	32,5±3,62
M18 x 1,5 [0.71 x 0.059]	74±5	7,5±0,5	54,2±3,62
M20 x 1,5 [0.79 x 0.059]	98±10	10,0±1,0	72,3±7,23
M24 x 1,5 [0.94 x 0.059]	147±15	15,0±1,5	108,5±10,8
M27 x 3 [1.06 x 0.12]	226±20	23,0±2,0	166,3±14,5

(Dry)

Standard union nuts

Cap nut size diameter x pitch mm [in.]	Strength classification			Nominal diameter
	Nm	kpm	lbf.ft	
M14 x 1,5 [0.55 x 0.059]	39	4	29	63
M16 x 1,5 [0.63 x 0.059]	49	5	36	80
M20 x 1,5 [0.79 x 0.059]	78	8	58	100
M22 x 1,5 [0.87 x 0.059]	98	10	72	120
M27 x 1,5 [1.06 x 0.059]	157	16	116	150
M30 x 1,5 [1.18 x 0.059]	196	20	145	180
M30 x 1,5 [1.18 x 0.059]	196	20	145	200
M33 x 1,5 [1.30 x 0.059]	245	25	181	220
M36 x 1,5 [1.42 x 0.059]	294	30	217	254

(Dry)

High pressure fuel injection pipes

Cap nut size diameter x pitch mm [in.]	Strength classification		
	Nm	kpm	lbf.ft
M12 x 1,5 [0.49 x 0.059]	39±5	4±0,5	29±3,6
M14 x 1,5 [0.55 x 0.059]	49±5	5±0,5	36±3,6
M18 x 1,5 [0.71 x 0.059]	59±1	6±1,0	43±7,2

(Dry)




Identification numbers

Type plates with identification numbers can be found on the engine and the transmission or generator. This information must always be used as a reference when ordering service and spare parts.

Engine
 Product designation
 Serial and basic engine number
 Product number

Certification, IMO
 Decal, part No.
 Approval No.....

Transmission / Generator
 Product designation
 Serial number
 Product number



VOLVO PENTA
 Serial No. Spec No.
 Model
 Rated power Kw/ HP
 Rated speed min⁻¹
 Manufactured by Mitsubishi Heavy Industries, Ltd
 Sagamihara, Japan for
VOLVO PENTA

Sea trial data

Date

Name

Vessel

Engine no.

Miscellaneous

Engine speed rpm

Vessel speed knots

Ambient/eng. room temp. °C

Sea water temp. °C

Eng. cooling water out Left bank °C

Eng. cooling water out Right bank °C

Cooler in °C

Cooler out °C

Eng. cooling water in °C

Lubrication oil pressure Bar

Lubrication oil temp. °C

Air intake Left bank °C

Air intake Right bank °C

Charge air temp. Left bank °C

Charge air temp. Right bank °C

Charge air press. Left bank Bar

Charge air press. Right bank Bar

Exhaust gas temp. Left bank °C

Exhaust gas temp. Right bank °C

Exhaust gas temp. common °C

Fuel temp. engine in °C

Fuel press. Bar

Type and brand of lubrication oil

Type and brand of coolant

Mixture of coolant

Type of fuel during normal operation

All values to be measured at full load. All values to be measured with approved instrumentation.
If in doubt mount your own equipment.

Notes

A series of horizontal dotted lines for taking notes.

A series of horizontal dotted lines for writing.

A series of horizontal dotted lines spanning the width of the page, providing a template for writing.

