



- (K) LOWER EDGE TO BE CUT ACC. TO HULL FROM
- (●) REF. POINT SEE INST HANDBOOK PUBL No 774/2078
- (1) LIFTING DEVICE
- (2) WATER INLET, SEA WATER PUMP FOR HOSE ID 32
- (3) EXHAUST ELBOW FOR HOSE ID 89
- (4) AIR FILTER
- (5) OIL FILLING
- (6) OIL DIPSTICK ENGINE
- (7) OIL FILTER
- (8) OIL DRAIN FOR PUMP, ENGINE
- (9) OIL DIPSTICK S-DRIVE
- (10) OIL FILLER CAP S-DRIVE
- (11) WATER OUTLET, SEA COCK FOR HOSE ID 32
- (12) WATER INLET
- (13) SEA WATER PUMP
- (14) WATER FILLER CAP FRESH WATER
- (15) HEAT WATER OUTLET
- (16) HEAT WATER INLET
- (17) FUEL CONNECTION FOR HOSE ID 9
- (18) FUEL RETURN CONNECTION FOR HOSE ID 9
- (19) FUEL FILTER
- (20) SPEED CONTROL LEVER
- (21) CONNECTION BOX FOR EXTENSION CABLE
- (22) BATTERY MINUS (-) CONNECTION
- (23) PLUS (+) CONNECTION FOR CHARGING DISTRIBUTOR
- (24) STARTER BATTERY PLUS (+) CONNECTION
- (25) GEAR SHAFT CONTROL CABLE
- (26) AIR INLET SILENCER
- (27) WATER DRAIN, FRESH WATER
- (28) WATER DRAIN, SEA WATER
- (29) THROTTLE CONTROL CABLE

SCALE 15

Plus d'informations sur : www.dbmoteurs

<p>For more information and details of the engine and its accessories, please refer to the Volvo Penta Handbook, Part 1, 1975 / 1985.</p> <p>VOLVO PENTA</p>	<p>SYMBOLS EXPLANATIONS AND DIMENSIONS (SEE PART 1 OF THE 53 DRAWINGS)</p>	<p>ENGINE INSTALLATION 1975 / 1985</p>	<p>INSTALLATION DRAWING 3591001</p>
	<p>3591001</p>	<p>02</p>	<p>113</p>
	<p>1</p>	<p>1</p>	<p>1</p>